



O W N E R S M A N U A L

BobCat / AquaCat

3.5
HIGH PERFORMANCE



HYDRAMASTER
Corporation

LIST OF PHOTOS

BobCat (front view, features labeled).....	7
BobCat (side view, features labeled).....	7
AquaCat (front view, features labeled).....	8
AquaCat (side view, features labeled).....	8
Cat Pump Model 290.....	11
Dismantling Cat Pump.....	13
Vanguard OHV Engine.....	21

HOURS


Monday -- Friday
8:00 am To 5:00 pm
PACIFIC STANDARD TIME



PST



ROCK MT.



CENTRAL



EASTERN

TELEPHONE NUMBERS

(206) 775-7272 General Offices
(206) 775-7276 Parts Department
(206) 775-7275 Service/Warranty
(206) 771-7156 FAX

LIST OF ILLUSTRATIONS

GENERAL INFORMATION

Plywood Installation (on truck bed).....	4
Astroturf and Roof Vent.....	4
Machine Configuration.....	5
Machine Tie Down Cleats, BobCat Only.....	5
Propane Tank Plumbing, BobCat Only.....	5
Thru-floor Gas Hook-up and Installation.....	5

Water Hardness Map.....	6
Water Softener Hook-up.....	6

WATER & CHEMICAL SYSTEMS

BobCat Water Flow.....	10
AquaCat Water Flow.....	10
Chemical Proportioning and Level Control.....	10

CAT PUMP

Pumping Section Cut-away.....	13
Piston Model 290 Exploded View.....	14

Bypass Valve Assembly.....	17
AquaCat Water Flow.....	17

VACUUM SYSTEM

Vacuum Flow.....	18
Vacuum Tank Filter Bag.....	18
Blower Lube Port.....	18
Vacuum Blower Motor Lubrication.....	20

VANGUARD OHV ENGINE

Oil Viscosity Chart.....	22
Oil Fill and Dip Stick.....	22

Engine Components.....	22
Engine Components (continued).....	23
Carburetor Adjustment Screws.....	23
Governed Idle Spring.....	23
Oil Filter / Oil Drain.....	24
Round Dual Air Cleaner Element.....	24
Square Dual Air Cleaner Element.....	24
Round Dual Element.....	25

Cooling System.....	25
Spark Plug.....	25
Fuel Filter.....	25

ELECTRICAL SYSTEM

Electrical Diagram.....	31
-------------------------	----

CLEANING & CHEMICALS

pH Chart.....	33
Cleaning Stroke Method.....	33

BOBCAT HEATING SYSTEM

Propane Pilot Light.....	34
--------------------------	----

CLEANING WAND

Wand Valve Assembly.....	35
Jet Assembly.....	35
Wand Assembly.....	35

TABLE OF CONTENTS

GENERAL INFORMATION

Warning and Caution.....	2
How the Systems Works.....	2
HydraMaster Hours & Phone Numbers.....	2
BobCat Machine Specifications.....	3
AquaCat Machine Specifications.....	3
Purchaser's Responsibility.....	4
Sales Representative's Responsibility.....	4
Truck Preparation.....	4
Placement of Unit in Vehicle.....	4
Truck Preparation Illustration.....	4
Machine Installation.....	5
Propane Tank Location, BobCat Only.....	5
Spare Parts Recommendation.....	5
Parts Order.....	5
Hard Water Area Map.....	6
Water Softener.....	6
Wastewater Disposal Advisory.....	6

BOBCAT OPERATING INSTRUCTIONS

Start Up.....	7
Shut Down.....	7
Flood Damage Work.....	7

AQUACAT 3.5 OPERATING INSTRUCTIONS

Start Up.....	8
Shut Down.....	8
Flood Damage Work.....	8

OPERATING PRECAUTIONS

Machine Adjustments.....	9
Cautions and Warnings.....	9

WATER & CHEMICAL SYSTEMS

Water/Chemical Flow Operation.....	9
BobCat Water Flow.....	10
AquaCat Water Flow.....	10
Chemical System Maintenance.....	10
Chemical Tank Trouble Shooting Guide.....	11

CAT PUMP

Cat Pump Model 290 Operating Instructions.....	11
Cat Pump Specifications.....	11
General Information for Cat Pump Repair.....	12
Servicing the Discharge Valves & Valve Seats.....	12
Servicing the Pumping Section.....	12
Servicing Sleeves and Seals.....	12
Service Kits.....	13
Model 290 Parts List.....	14
Cat Pump Trouble Shooting Guide.....	15-16
High Pressure Pump Trouble Shooting Guide.....	17
Bypass Parts List.....	17

VACUUM SYSTEM

Information.....	18
Vacuum Tank Filter Bags.....	18

Vacuum Blower Trouble Shooting Guide.....	19
Vacuum Blower Warranty.....	20
Vacuum Blower Lubrication.....	20

VANGUARD OHV ENGINE

Operating & Maintenance for Model 303400 (16 HP) Engine.....	21
International Symbols Used in this Manual.....	21
In the Interest of Safety.....	21
Warning: DO NOT.....	21
Warning: DO.....	22
Before Starting.....	22
Oil Recommendations.....	22
Fuel Recommendations.....	23

Carburetor Adjustments.....	23
-----------------------------	----

ENGINE MAINTENANCE.....	24
Oil Change.....	24
Air Cleaner Maintenance.....	24
Clean Engine, Rotating Screen, Cooling System, Spark Arrester.....	25
Replace Spark Plugs, Replace Fuel Filters.....	25-26
Engine Maintenance Schedule.....	26

General Information about Engine.....	27
Storage Instructions.....	27
Service & Repair Information.....	27

Vanguard Engine Warranty.....	28
Superseding Warranty.....	28
Limited Warranty for Vanguard Engines.....	28
Warranty Period.....	29

ENGINE TROUBLE SHOOTING.....	30
------------------------------	----

ELECTRICAL SYSTEM

Electrical System and Trouble Shooting Guide.....	31
---	----

FREEZE PROTECTION

BobCat.....	32
AquaCat.....	32

CLEANING & CHEMICALS

Precautions.....	33
Cleaning Stroke Procedure / Over-Wetting.....	33

BOBCAT HEATING SYSTEM

Information.....	33
Heater Operating Instructions.....	34
Heater Trouble Shooting Guide.....	34

CLEANING WAND

Wand, Jet Assembly & Wand Assembly Parts Lists.....	35
---	----

MAINTENANCE

Procedures.....	36
Overall Care of Unit.....	36
Maintenance Logs.....	37-38

HYDRAMASTER WARRANTY

Warranty Information.....	39
Warranty Procedure.....	39
How to Order Parts.....	39
Parts Orders.....	39
One Final Note.....	39
BobCat/AquaCat Limited Warranty Plan.....	40

GENERAL INFORMATION

This manual contains installation and operation instructions as well as information required for proper maintenance, adjustment and repair of this unit. Since the first and most important part of repair work is the correct diagnosis of the trouble, a general trouble shooting section and component manual troubleshooting charts have been included for your convenience.

Unlike a garden tractor, lawn mower or cement mixer, all having one or two functions to perform, the truck-mounted carpet cleaning plant has many functions to perform simultaneously.

- * Engine has to run at a consistent RPM.
- * Vacuum has to pull air and dirty water back from cleaning site.
- * Water pump provides stable pressure at proper water flow for cleaning.
- * Chemical has to be injected into the water stream at the right concentration.
- * Heater must maintain proper heat.
- * Vacuum tank must store dirty water until drained.

As you can see, it is not just a turn key operation with one thing to worry about, **Does it start?!**

◆ WARNING ◆

The manufacturer uses this symbol throughout the manual to warn of possible injury or death.

◆ CAUTION ◆

This symbol is used to warn of possible equipment damage.

HOW THE SYSTEMS WORK

THE BOBCAT SYSTEM WORKS AS FOLLOWS:

The water system takes incoming water at tap (low) pressure, automatically combines it with chemicals from the chemical system, pumps it under pressure through the heating system and out to the cleaning tool. After being sprayed into the carpet, the water/chemical/soil solution is extracted by the vacuum system and returned to the waste recovery tank.

There is no guess work in the manufacture of these highly advanced cleaning plants. There must also be no guess work in preparing it to get the job done in the field. It is the purpose of this manual to help you properly understand, maintain and service your cleaning plant. Follow the directions carefully and you will be rewarded with years of profitable trouble-free operation.

It is imperative that **no section** be overlooked when preparing for operation of this equipment.

THE AQUACAT 3.5 SYSTEM WORKS AS FOLLOWS:

The AquaCat 3.5 High Performance Heat Exchanger system is a highly engineered cleaning plant, designed by HydraMaster Corp. The system utilizes a dynamic heating system comprised of two separate exhaust heat exchangers for capturing "free heat".

Water is fed into the machine at tap pressure. It is combined automatically with cleaning solution as it enters the mix tank. The solution is then picked up by the high pressure pump and pressurized to the desired level. The solution then travels to the bypass assembly where it is distributed out to the wand and back into the machine. The solution going back into the machine splits flow and travels through the two exhaust heat exchangers. After being heated, the solution returns to the mix tank where it is picked up by the pump again.

When the cleaning solution reaches a pre-set high temperature, it is released from the system and directed to the recovery tank, then cool water enters the system to regulate the temperature.

As there is no guess work in the manufacture of these highly advanced cleaning plants, there must be none in preparing it to get the job done in the field. It is the purpose of this manual to help you properly understand, maintain and service your cleaning plant. Follow the directions carefully and you will be rewarded with years of profitable trouble-free operation.

It is imperative that **no section** be overlooked when preparing for operation of this equipment.

BOBCAT MACHINE SPECIFICATIONS

FRAME: 18" W, 53" L, 34" H. Steel with baked-on epoxy finish.

WEIGHT: Model 3.0: 485 lbs. (dry weight).
Model 3.5: 500 lbs (dry weight).

COWLING: Steel with baked-on Epoxy finish.

ENGINE: 16 HP Briggs & Stratton V-Twin. Steel sleeved cylinders, ducted.

IGNITION: Magneto key start. Solid state ignition.

HI-PRESSURE PUMP: Tri-Plex piston -- Cat 290 -- 3.5 GPM
-- 1200 PSI -- @ 1200 RPM.

VACUUM BLOWER: Model 3.0: 3ML Sutorbilt w/14 HG safety relief.
Model 3.5: 3LFS Sutorbilt w/12 HG safety relief.

CHEMICAL SYSTEM: Electro-mechanical, flow meter controlled.

HEATER: Propane fired, thermostatically controlled (120,000 BTU).

INSTRUMENTS: 0-1000 High pressure gauge, Temperature gauge,
Vacuum gauge, Hour meter, Chemical flow meter,
Ignition key start .

RECOVERY TANK: Model 3.0: 52 gallon aluminum, epoxy finish.
Model 3.5: 70 gallon aluminum, epoxy finish.

CLEANING WAND: Stainless steel 11" with heat cover handle, and forward
guide handle.

HI-PRESSURE HOSE: 1/4" High-temperature lined/vinyl covered safety
orange with brass quick connects.

VACUUM HOSE: 2" Reinforced safety orange.
1 1/2" Reinforced safety orange.

STANDARD EQUIPMENT: Power console, Vacuum recovery tank, 11"
stainless steel cleaning wand, 100'-1/4" high pressure hose, 100'-2" vacuum
hose, 10'-1/2" vacuum hose, Through floor connections for gasoline and
propane hook-up, Tie-down cleats, Vacuum hose connections, 5 gallon
chemical jug, Owners manual.

OPTIONAL FEATURES: Stair tool, Steel legs w/Casters, additional 2"
vacuum Hose in 50' lengths, Additional 1/4" pressure hose in 50' lengths,
Pressure washing gun, Spare parts package.

DESIGN CHANGES: This information is accurate at the time of printing.
However, the design and specifications of HydraMaster equipment are
subject to continued change and refinement.

AQUACAT MACHINE SPECIFICATIONS

FRAME: 21" W, 50" L, 28" H. Steel with baked-on epoxy finish.

WEIGHT: 500 lbs. complete.

COWLING: Steel with baked-on Epoxy finish.

ENGINE: 16 HP Briggs & Stratton V-Twin, steel sleeved cylinders, ducted.

IGNITION: Magneto key start, solid state ignition.

HI-PRESSURE PUMP: Tri-Plex piston -- Cat 290 -- 3.5 GPM
-- 1200 PSI -- @ 1200 RPM.

VACUUM BLOWER: 3LFS Sutorbilt w/12 HG safety relief.

CHEMICAL SYSTEM: Electro-mechanical, flow meter controlled.

HEATER: 2 exhaust heat exchangers.

INSTRUMENTS: 0-1000 High pressure gauge, Temperature gauge,
Vacuum gauge, Hour meter, Chemical flow meter,
Ignition switch.

RECOVERY TANK: 70 gallon aluminum, epoxy finish.

CLEANING WAND: Stainless steel 11" with heat cover handle, and forward
guide handle.

HI-PRESSURE HOSE: 1/4" High-temperature lined/vinyl covered, safety
orange with brass quick connects.

VACUUM HOSE: 2" Reinforced safety orange.
1 1/2" reinforced safety orange.

STANDARD EQUIPMENT: Power console, Sound suppression package,
Level temperature exchange heater, Vacuum recovery tank, Carpet cleaning
wand, Chemical jug, Chemical jug holder, Owners Manual, 100' - 2"
vacuum hose, 10'-1 1/2" vacuum hose, 100' Super-flex solution hose, 10'-
1 1/2" drain hose, Battery box with holder, Fuel system kit, Van decal, Van
installation kit.

DESIGN CHANGES: This information is accurate at the time of printing.
However, the design and specifications of HydraMaster equipment are
subject to continued change and refinement.

PURCHASER'S RESPONSIBILITY

PRIOR TO ARRIVAL OF UNIT:

1. Install 5/8" exterior plywood flooring in vehicle and cover with artificial turf.
2. Have belly mounted propane tank installed on vehicle. Tank must be propane vapor type (for BobCat only).

CAUTION

3. Purchase heavy duty 42-60 amp hour battery and have battery 'slow' charged if new. If battery is not fully charged damage can occur to the engine charging regulator.

READING OF OWNERS MANUAL: It is the purchaser's responsibility to read the unit operation manual and to familiarize himself with the information contained therein. **Special attention should be paid to all CAUTIONS and WARNINGS.**

SALES REPRESENTATIVE'S RESPONSIBILITY

ACCEPTANCE OF SHIPMENT:

1. If unit shows any outward signs of damage, do not sign the delivery receipt until you have closely inspected the unit and noted any damage on the delivery receipt. Have the freight company representative acknowledge the damage by signing the notation of damage on the delivery receipt.
2. The salesman from whom you purchased your unit is responsible for supervising the correct installation of the unit in your vehicle and thoroughly training you in its operation, maintenance and precautions.

CORRECT INSTALLATION INCLUDES: Installation of through-floor fittings for propane and gasoline fuel lines; installing propane regulator included with unit, outside vehicle; placing unit and recovery tank in vehicle and securing them with bolts or tie down cleats; connecting all propane and gasoline lines; connecting battery; checking pump, vacuum blower and engine oil levels, prior to starting unit; starting unit to check engine to see that all systems function normally; also checking all hoses, wands, etc., for correct operation.

TRAINING SHALL INCLUDE: Thorough review of the operation manual with purchaser; instruction and familiarization in: how to correctly start up and shut down unit; how to correctly clean with the unit; how, where and how often to check and change component oil levels; how the unit's systems work; how to troubleshoot the unit; how to do basic repairs; safety precautions and their importance; freezing damage and how to avoid it and a thorough review of the unit warranty and warranty procedures.

TRUCK PREPARATION

The manufacturer recommends the installation of plywood flooring covered with poly propylene backed astroturf (do not use rubber-backed) in the vehicle prior to installation of machine. This provides a metal to cushion mounting rather than metal to metal, provides insulation and makes an attractive van interior. Astroturf should be color keyed to van interior.

Materials Needed:

1. 2 sheets 4x8x5/8" exterior plywood
2. 6'x12' piece of commercial astroturf
3. 16 - 1 1/2" sheet metal screws
4. 1 quart marine adhesive (optional)
5. 1 staple hammer w/1/2" staples

(See illustration for correct placement of plywood flooring)

PLACEMENT OF UNIT IN VEHICLE

THERE ARE TWO RECOMMENDED UNIT PLACEMENTS:

A. SIDE DOOR: Most installations are side door. This provides rear access for accessories and hoses as well as unobstructed access to component/working side of machine, thus making it a bit easier to perform maintenance and/or repair without removing unit from the truck.

B. REAR DOOR: Although this location partly limits working access, it does direct the noise away from the cleaning site. Some cleaners in the colder areas prefer this location because it puts the weight mass over the rear wheels for better traction in ice and snow. Rear mounting requires the unit to be slid to the right side as far as possible. This not only provides adequate working space on the component side of the unit but also makes better weight distribution inside the van (engine and component weight line up over drive shaft). Also, it is physically easier to load unit into rear door due to height of van bed.


WARNING

Ensure that machine is well secured to the floor of van with hardware supplied. Sudden or crash stop will cause machine to rocket forward, all 500 lbs. worth! Protect yourself and the machine. **SECURE IT!**

TRUCK PREPARATION ILLUSTRATION

FIRST, cover the truck bed with 5/8" plywood using metal screws to secure it as shown.


Plywood Installation



SECOND, select the appropriate color astroturf to match your van and cover the plywood and staple in place. A standard van requires a piece 6 feet by 12 feet.

THIRD, HydraMaster strongly recommends an aluminum roof vent be installed over the location selected for mounting the machine. HydraMaster also highly recommends a flue be installed between the top of the heater and the roof vent. This will allow hot air from the heater to escape.


Astroturf & Roof Vent



MACHINE INSTALLATION

There are two locations to place the machine, in the side door or in the rear door, as mentioned in the section titled "Placement of Unit." The standard way to configure the unit is, as shown in the illustration, with the recovery tank beside the unit. An alternative method, not shown, would be to put the recovery tank behind the unit. (The standard machine does not come with enough hardware to allow for mounting of the tank behind the machine. If this configuration is chosen please contact HydraMaster for more information.)

HydraMaster recommends that the exhaust for the machine be piped through the floor of the vehicle. It is important that the machine be placed as close to the door as possible so that outside air can be pulled into the engine for proper cooling.



◆ **WARNING** ◆


It is recommended by the manufacturer that the exhaust from the front of the machine be vented down under the truck to prevent carbon monoxide from entering the job site. Always park the truck so the exhaust is blowing away from the job site.

The manufacturer also recommends that installation of aluminum vents in the truck roof to allow heat from the heater to escape.

◆ **WARNING** ◆

Never operate this machine with a portable propane tank or a portable gas can inside the truck, doing so increases the risk of a fire or explosion.

Mount a fire extinguisher just inside the rear or side door for emergencies.




PROPANE TANK LOCATION, BOBCAT


Either the 10 gallon or 16.5 gallon propane tank will fit this location. Have you local propane dealer install the tank you select and purchase. The machine will come with the proper propane regulator. (Tank must have vapor outlet.)

◆ **WARNING** ◆

Professional installation of fuel systems is strongly recommended. Always ensure compliance with state and local regulations pertaining to fuel installations.



Thru-floor Gas Hook-up and Installation



SPARE PARTS RECOMMENDATION

Because your truck-mounted unit is capable of generating several hundred dollars per day, down-time on the unit can be very expensive. In order to minimize such down-time, it is strongly recommended by the manufacturer that you purchase and keep in your truck the parts listed below.

PARTS ORDERS


To expedite your parts needs, please call your sales representative. In most instance, he either stocks or has access to parts through a regional service center. In the event parts are unavailable locally, contact the factory and coordinate your needs. If this becomes necessary, always indicate the method of shipment you desire, i.e. UPS, Blue Label, Air Freight, Air Express, etc. HydraMaster Parts Department. Phone (206) 775-7276.

PART NO.	DESCRIPTION	QTY.
106-030	Engine spark plug	2
049-012	Round air cleaner	BobCat 1
049-038	Square engine air cleaner	AquaCat 1
049-014	Engine oil filter	1
078-015	Flow meter kit	1
078-024	Wand valve plunger kit	1
078-034	Pressure bypass valve kit	1
076-005	Spray jet 8006E	1
076-003	Spray jet 8004E	1
049-028	Recovery tank filter bag	2
049-023	Screen, garden hose	6
078-001	Cat 290 short cup kit	BobCat 1
078-004	Cat 290 hot cup kit	AquaCat 1
052-050	440 Male quick connect	1
052-051	440 Female quick connect	1
052-052	660 Male quick connect	1
052-053	660 Female quick connect	1
010-020	Belt pump drive Ax-25	1


HARD WATER AREA MAP

The quality of water varies greatly throughout the United States and influences the reliability and efficiency of equipment in direct proportion to its level of hardness. The map below defines areas which compromise fluid related components such as hoses, fittings, heaters, pumps, valves and water cooled engines.

Cleaning efficiency and equipment life is increased, chemical use decreased and the appearance of cleaned carpets enhanced when water softeners are incorporated in hard water areas. Manufacturer strongly urges the use of water softener units in areas exceeding 3 1/2 grains per gallon. Using the legend as a reference, determine the quality of water in your area and take action immediately should it be necessary.



Water Softener Hook-up



WATER SOFTENER

Many areas of the country have an excess of minerals in the water which results in what is commonly called "hard water". These minerals tend to adhere to the insides of heater coils and other parts of the machines causing damage and a loss of cleaning effectiveness.

Reports from several of our machine users commending the results of the use of water softeners in conjunction with their machines prompts us to recommend the procedure to everyone in a "hard water" area.

The relatively low cost of a water softener service is more than made up for in the increased life of machine parts and continued cleaning efficiency. The water softener will also increase the effectiveness of the cleaning chemical being used, therefore, less chemical will be needed.

Contact a water softener distributor in your area for information on the rental of a simple water treatment unit to carry in your truck. Be sure to change the water softener in accordance with the capability of the softener. Example: If the softener will treat 900 gallons of water and machines uses an average of 30 gallons per hour of use, and an average of 5 hours a day, would be 150 gallons a day. 5 days would equal 750 gallons of water, therefore, the softener would be changed every 6 working days for maximum softening.

WASTEWATER DISPOSAL ADVISORY

There are laws in most communities prohibiting the dumping of recovered "gray" water from carpet cleaning in any place but a sanitary treatment system.

This cleaning rinse water, recovered into your unit's vacuum tank, contains materials such as detergents, which must be processed before being safe for streams, rivers and reservoirs.

IN ACCORDANCE WITH THE EPA, STATE AND LOCAL LAWS, DO NOT DISPOSE OF WASTEWATER INTO GUTTERS, STORM DRAINS, STREAMS, RESERVOIRS, ETC.

In most cases, an acceptable method of wastewater disposal is to discharge into a municipal sewage treatment system after first filtering out solid material such as carpet fiber. Access to the sanitary system can be obtained through a toilet, laundry drain, carwash drain, RV dump, etc. Permission should first be obtained from any concerned party or agency.

One disposal method which usually complies with the law is to accumulate the wastewater and haul it to an appropriate dump site. Another solution to the disposal problem is to equip yourself with an Automatic Pump-Out System. These systems are designed to remove wastewater from the extractor's recovery system and actively pump the water through hoses to a suitable disposal drain. Property designed, they will continuously monitor the level of wastewater and pump it out simultaneously to the cleaning operation. The hidden benefit of this process is that the operator doesn't have to stop his cleaning to empty the recovery tank. HydraMaster makes an A.P.O. System available which can be ordered with new equipment or installed later.

The penalties for non-compliance can be serious. Always check local laws and regulations to be sure you are in compliance.

BOBCAT OPERATING INSTRUCTIONS

START UP

1. Perform daily/periodic maintenance as specified in this Owners Manual (page 36).
2. Connect all required hoses.
3. Connect cleaning tool to length of hose required to perform cleaning.

CAUTION

4. Mix tank must be full prior to ignition.

5. Start engine (choke as required). Engine is at operating speed (recommended - 2800 RPM). Allow warm-up period of 2-5 minutes.
6. Spray wand to void all air from system. When the mix tank begins a fill cycle, the chemical flow meter may be adjusted to your desired setting.
NOTE: Chemical flow meter set at 5 GPH is a 1 to 30 mix ratio and 10 GPH is 1 to 15 ratio. When flow meter is set at 10 GPH, you will be using what most chemical manufacturers recommend at 5 GPH.

7. Once all air is voided from system, heater may be ignited.
NOTE: If not familiar with operation of this heater, refer to heater section of this Manual (page 33).

A. Open propane valve on the tank.

B. Ignite pilot on the heater.

C. To ignite burner, turn dial to "on" position.

NOTE: If you suspect that the unit has been frozen - **DO NOT** light the heater. Thaw the heater and check for leaks.

8. Turn on burner, adjust dial to normal or slightly below for 200°F.

9. Commence cleaning operation.

NOTE: Recommended carpet cleaning pressure is 250-300 PSI.

SHUT DOWN

1. Turn heater to "off" position. Spray wand for at least 3 minutes to allow the heater coils to cool.
2. Close valve on propane tank.
3. Remove vacuum hose.
4. Flush clear water through chemical system for 10 seconds (vinegar should be rinsed through system weekly.) Turn off chemical flow meter.
5. Turn on cleaning tool to flush chemical from unit hoses and cleaning tool.
NOTE: If freeze guard is necessary, perform step 1 of freeze guard procedure at this time (page 32).

6. At this time, the blower should be lubricated with LPS 1.

7. Shut engine down.



8. Drain vacuum tank. Vacuum filter should be cleaned prior to mobilization of van.

NOTE: If freeze guard is necessary, perform steps 2-3 of freeze guard procedure at this time.

FLOOD DAMAGE WORK

CAUTION

Caution must be exercised to prevent the water pump from overheating during long periods of vacuum work such as water damage recovery.



AQUACAT 3.5 OPERATING INSTRUCTIONS

START UP

1. Perform daily/periodic maintenance as specified in this Owners Manual (page 36).
2. Connect all required hoses.
3. Connect cleaning tool to length of hose required to perform cleaning.

◆ CAUTION ◆

4. Mix tank must be full prior to ignition.

5. Start engine (choke as required). Engine is at operating speed (recommended -3000 RPM). Allow warm-up period of 2-5 minutes.
6. Spray wand to void all air from system. When the mix tank begins a fill cycle, the chemical flow meter may be adjusted to your desired setting.
NOTE: Chemical flow meter set at 5 GPH is a 1 to 30 mix ratio and 10 GPH is 1 to 15 ratio. When flow meter is set at 10 GPH, you will be using what most chemical manufacturers recommend at 5 GPH.

7. Run machine for several minutes under load (8 to 10" HG) until desired temperature is achieved.

8. Commence cleaning operation.

NOTE: Recommended carpet cleaning pressure is 250-300 PSI.

SHUT DOWN

1. Remove vacuum hose.
2. Flush clear water through chemical system for 10 seconds (vinegar should be rinsed through system weekly). Turn off chemical flow meter.
3. Turn on cleaning tool to flush chemical from unit hoses and cleaning tool.
NOTE: If freeze guard is necessary, perform steps 1 & 2 of freeze guard procedure at this time (page 32).



6. At this time, the blower should be lubricated with LPS 1.
7. Shut engine down.
8. Drain vacuum tank. Vacuum filter should be cleaned prior to mobilization of van.

NOTE: If freeze guard is necessary, perform steps 3-4 of freeze guard procedure at this time.

FLOOD DAMAGE WORK

◆ CAUTION ◆

Caution must be exercised to prevent the water pump from overheating during long periods of vacuum work such as water damage recovery.



OPERATION PRECAUTIONS

MACHINE ADJUSTMENTS

Although this unit has been factory adjusted, it may require additional adjustments to achieve optimum performance; i.e. altitude may require carb adjustment and ambient temperatures may require heat control adjustment. When required, consult an authorized representative.

◆ CAUTION ◆

ENGINE COOLING

Units employing air cooled engines must not be enclosed within a van with doors and windows closed. Excessive temperatures within the engine will result in premature engine failure and a compromise of applicable warranty.

◆ CAUTION ◆

LEVEL OPERATION

During operation, van or trailer must be parked on level ground not to exceed + or -10°. Failure to insure proper leveling may prevent proper internal lubrication of engine, vacuum and/or high pressure components.

◆ CAUTION ◆

FREEZE PROTECTION

Mother nature gives little warning as to her cold spells. Therefore, protecting this equipment from freezing will save costly down-time. Placing an electric heater in the truck or parking the truck indoors, will help to insure against freezing.

◆ CAUTION ◆

HEATER

Never pile things around the heater, i.e. hoses, boxes, chemical jugs, etc., as this will block the flow of air required for a clean burning heater.

◆ CAUTION ◆

OPEN FLAME

Remember that this heater is an open flame, therefore, do not remove engine gas line while trouble shooting or store any flammable material in the truck with heater operating.

◆ WARNING ◆

STRONG PROPANE ODOR

Never light the heater if you smell a strong odor of propane around the heater.

◆ WARNING ◆

HOT SURFACES

During the operation of this equipment many surfaces on the machine will become very hot. When near the van for any reason care must be taken not to touch any hot surface, such as heater, engine, exhaust, etc.

◆ WARNING ◆

LIGHTING HEATER

Never put your face down close to the opening of the heater when lighting.

◆ WARNING ◆

NO SMOKING

It is unsafe to smoke in or around the vehicle.

◆ WARNING ◆

MOVING PARTS

Never touch any part of the machine that is in motion, severe bodily injury may result.

◆ WARNING ◆

CARBON MONOXIDE

This unit generates toxic fumes. Position the vehicle so that the fumes will be directed AWAY from the job site.

DO NOT PARK where exhaust fumes can enter a building through open doors or windows, air conditioning units or kitchen fans.

◆ WARNING ◆

TOXIC FLUMES

Do not occupy the vehicle when the cleaning equipment is operating. Toxic fumes may accumulate inside a stationary vehicle.

WATER & CHEMICAL SYSTEMS

WATER/CHEMICAL FLOW OPERATION

This electro-mechanical system has been designed to be simple and trouble free. Incoming water flows first through the Solenoid Control Valve (1) (see illustration on next page) and the low pressure Chemical Injector (2) which are both mounted on the exterior of the mix tank. As the water passes through the Chemical Injector, it is automatically proportioned with a predetermined quantity of detergent. The Mix Tank (3) is equipped with two different float switches, the Water Level Float (4) responds to the level in the tank and will maintain the proper volume of solution to be reserved for the water pump. The secondary, Low Water Float switch (5) is a safety switch that is designed to protect your system from sudden or unexpected loss of water supply. If, for example, the water source at the house were turned off, the water level of the mix tank would drop, activating the secondary switch, which automatically disengages the system and prevents the water pump from running dry.

The desired chemical injection ratio may be obtained by an adjustment of the Chemical Flow Meter (6) during the fill cycle of the mix tank. Water must be flowing into the mix tank in order to adjust the chemical mix. The chemical will flow from the Chemical Jug (7) to the Chemical Flow Meter, then to the Chemical Injector where it is proportioned into the Mix Tank at the desired chemical setting.

NOTE: With this unique chemical system, the chemical flow is proportioned only during the filling cycles of the Mix Tank, not during the direct spraying of the wand. Therefore, it is possible that as your wand is spraying, you may have no chemical flow. Also, the converse is true in that you may not be spraying your wand, but if the mix tank is in a filling cycle, your Chemical Flow Meter may be active at the desired flow rate.

The chemical proportioning system will mix chemical with water at a 1 to 30 ratio when the Flow Meter is set at 5 GPH, or a 1 to 15 ratio when the Flow Meter is set at 10 GPH.


(continues, next page)

BOBCAT WATER FLOW

At this point in the flow, solution (water with chemical) will now be siphoned from the bottom of the Mix Tank to the inlet of the Water Pump (8). When the wand is not using solution by spraying, the solution will be bypassed from the bottom of the brass Pressure Relief Valve (9), back to the Mix Tank.

When the wand is spraying, the solution continues its flow to the Water Heater (10). The coils of this heater have a capacity of up to 2 gallons, therefore it is extremely important that all air pockets are bled out of the heater prior to initial start-up. This may be achieved by running the water system, without the heater on, for approximately 60 seconds.

BobCat Water Flow



AQUACAT WATER FLOW


At this point in the flow, solution (water with chemical) will now be siphoned from the bottom of the Mix Tank to the inlet of the Water Pump (8). In the pump the water is pressurized and then discharged through a rubber pulsation hose down to the pressure relief valve (9). From the pressure relief valve the water is automatically distributed to the cleaning wand and bypassed back to the mix tank, depending on water usage at the wand.

As the water travels back toward the mix tank from the pressure relief valve it flows through two exhaust heat exchangers which heat the cleaning water.


CHEMICAL SYSTEM MAINTENANCE

The chemical lines may need to be flushed with vinegar periodically to prevent abnormal chemical build-up. This flushing may be done by removing the clear plastic hose from the Chemical Jug and inserting it into a one quart container of vinegar. This should be done with the Chemical Flow Meter setting on 10 GPH and the Water Heater "off". Simply spray water from the wand until the quart of vinegar is exhausted, then repeat the process with one quart of clear water to void all lines of vinegar.

Chemical Proportion and Level Control



AquaCat Water Flow



CHEMICAL TANK TROUBLE SHOOTING GUIDE

PROBLEM: Little or no chemical flow

Solution

Check that hoses at the Mix Tank (3) are secure. Check that the hose from the top of the Flow Meter (6) to the Chemical Injector (2) is secure with no kinks or leaks. Check that the adjusting cap on the side of the injector is not screwed all the way in. Check the s/s check valve inside the injector for chemical build-up and proper operation. Check the hose from the bottom of the Flow Meter to the Chemical Jug (7) for kinks, cracks, or bubbles.

Check the screen on the end of the hose which goes into the Chemical Jug. To check this screen for proper function, remove it from the plastic hose. If you cannot blow through it, then rinse it out with vinegar.

Check the Chemical Flow Meter (6) for obstructions or a sticking float.

Is incoming water pressure less than 30 PSI?

Cracked or defective Chemical Flow Meter (6)?

Check the filter screen in the Solenoid Control Valve (1).

PROBLEM: Inability to adjust chemical with the Flow Meter

Solution

Debris lodged behind teflon seat in Flow Meter valve.

Teflon seat on the valve stem may be loose. If deteriorated, replace O-Ring.

Insufficient water pressure. Locate new source.

PROBLEM: Solution reversing from Mix Tank, filling the Chemical Jug

Solution

Anti-siphon device clogged by chemical build-up (Anti-siphon device is located in the Chemical Injector (2) body — see page 10, Water Flow illustration).

Check for debris.

PROBLEM: Mix Tank overflows

Solution

Float switch (4) in the Mix Tank not moving freely, or defective.

To check switch: With a 12 volt test light and the float in the "up" position, there should be power through the switch.

To check relay: First check wiring against diagram. With 12 volt test light, and the Float Switch (4) in the "up" position there should NOT be power at the Solenoid Valve. With the Float Switch in the "down" position there should be power at the Solenoid Valve.

Solenoid Valve defective: Remove Solenoid Valve, disassemble and inspect diaphragm for cracks or tears.

PROBLEM: Mix Tank does not keep up with water output

Solution

Check incoming water pressure. Check garden hose quick connect assembly screen.

Check garden hose and/or feed hose to the Mix Tank for clog, kinks, or blockage.

Float Switch (4) in Mix Tank hanging up (not moving freely). Check filter screen in Solenoid Valve (1).



CAT PUMP MODEL 290 OPERATING INSTRUCTIONS

Products described hereon are covered by one or more of the following U.S. patents: 3558244, 3652188, 3809508, 3920356, and 3930756



P.O. Box 885 MINNEAPOLIS, MN 55440
Phone (612) 780-5440 — Telex 29-0275

• N.V. CAT PUMPS INTERNATIONAL S.A. •
Harmoniestraat 29
B 2000 Antwerp, Belgium
Phone (03) 237-72-24 — Telex 33947


• CAT PUMPS — A.G. •
Loretshohe 5
CH-8300 ZUG, Switzerland
Phone (42) 21-31-40 — Telex 885 180 cpag ch

• CAT PUMPS DEUTSCHLAND GmbH •
Rostocker Strasse 9
6200 Wiesbaden-Bierstadt, West Germany
Phone 0612-56 00 01/2 — Telex 41 86713

• CAT PUMPS (U.K.) LTD •
27 Station Industrial Estate, Fleet
Hampshire GU13 8QY England
Phone Fleet 22031 — Telex 858898

SPECIFICATIONS

Volume	3.5 GPM (13 L/M)
Discharge Pressure	1200 PSI (83 BAR)
Maximum Inlet Pressure	- 8.5 to + 40 PSI (-0.6 to + 2.8 BAR)
RPM	1200
Bore	0.787" (20mm)
Stroke	0.472" (12mm)
Crankcase Capacity	10 oz. (.3 L)
Inlet Port (1)	1/2" NPT (1/2" NPT)
Chemical Injection Port (1)	1/4" NPT (1/4" NPT)
Discharge Ports (2)	3/8" NPT (3/8" NPT) (1):.....1/2" NPT (1/2" NPT)
Pulley Mounting	Either side (Either side)
Shaft Diameter	0.650" (16.5mm)
Weight	12.1 lbs. (5.5 kg)
Dimensions	10.77"x9.06"x5.14" (273.5x230x130.5mm)



GENERAL INFORMATION FOR CAT PUMP REPAIR

As you remove your discharge manifold, there is a set of 3 check valves (which usually fall out during dismantling). If the surfaces of these check valves are dirty, or show signs of chemical build-up, it is probable that they would remain open causing pressure loss or pulsation. Upon inspecting the valves, make sure that the teflon button in the valve spring retainers are still intact. Also examine the discharge manifold. Look for problems such as cracks, chemical buildup or warping due to freezing. If this discharge manifold is warped, it will cause the check valves to stick and will result in loss of pressure.

The Cat pump cups are often the source of pressure loss. Upon inspection they may appear melted or torn, but often they will look good. Replace them anyway. There is no sure method of visually inspecting the cups. HydraMaster recommends changing cups whether they look good or not.

Anytime your pump is being dismantled, HydraMaster recommends replacement of all 'o' rings and seals. This is merely a convenience to the customer to make sure that the Cat pump is in top operating condition.

The Prrrrm-A-Lube seals located within the intake manifold will allow air to enter the pump if they are worn. Again, it is difficult to visually pinpoint a defective Prrrrm-A-Lube seal. Replace them all.

Repairing of Cat pumps is not a difficult task. However, before dismantling make sure you have the proper parts required.

- | | |
|----------------------------|-----------------------------|
| 1 - short (or hot) cut kit | 6 - piston sleeve 'o' rings |
| 3 - Prrrrm-A-Lube seals | 1 - bottle Cat oil |

Read instructions thoroughly, supplied in the Cat pump manual prior to dismantling and follow directions as stated. Oil all seals thoroughly prior to installation. (Remember, a newly scarred seal is no better than one you just took out.)

SERVICING DISCHARGE VALVES & VALVE SEATS

DISMANTLING

1. Loosen the 2 (M8) locking nuts approximately one turn.
2. Then remove the 2 (M8) flange nuts.
3. Grasp the discharge manifold with 3 fingers on the underside and tap with a soft mallet to remove.
4. Valve assemblies will remain with the manifold. Invert manifold and discharge valve assemblies should fall out.
5. Inspect discharge valves for wear or ridges. (Spherical valves due to their shape must be replaced when worn.)

REASSEMBLY

1. Place retainer in manifold chamber.
2. Next insert spring into center of retainer.
3. Place valve over spring with spherical (mooned) side up.
4. Next insert the valve seat.
5. Position manifold back onto pump.

NOTE: Exercise caution when inserting cylinders into manifold to avoid damaging cylinder o-rings.

6. Replace flange nuts on studs and hand tighten both sides. Then torque each side to 125 inch pounds.
7. Hand tighten locking nut.

◆ CAUTION ◆

When restarting the pump, check to see that there is no cylinder motion as this will cause premature failure of the cylinder o-rings. Center cylinder motion can be eliminated by switching with one of the end cylinders.

SERVICING THE PUMPING SECTION

DISMANTLING

1. Remove discharge manifold as described in the last section.
2. Slip cylinders out of inlet manifold. **NOTE:** Identify cylinders so they will be replaced in their original position (front to back).
3. Remove cotterpin, nut, and washer.
4. Next remove piston retainer, spacer, and piston assembly.
5. Remove inlet valve

REASSEMBLY

1. Examine inlet valve surface and reverse if damaged (both sides are lap surfaces).
2. Examine piston assembly for clean inlet surface. If damaged, replace and lubricate.

NOTE CUP INSTALLATION: Wipe cup inserter lightly with oil. Slip bac-cup ring onto piston. Force cup over inserter and square with all surfaces. Faulty cup installation causes premature failure.

3. Next replace piston spacer and retainer.
4. Slip washer onto rod, screw on nut and torque to 60 inch pounds.

NOTE: ALWAYS REPLACE WITH NEW COTTERPIN.

5. Examine cylinder walls for scoring or etching. These conditions will cause premature wear of your piston assemblies. Replace if worn or damaged.
6. Lubricate cylinder and replace o-rings and backup rings (if defective).
7. Position cylinders in their original order into manifold chambers and carefully slip over rod ends onto the pump.
8. Replace flange nuts on studs and hand tighten both sides. Then torque each side to 125 inch pounds.
9. Hand tighten locking nuts.

SERVICING THE SEALS AND SLEEVES

DISMANTLING

1. Remove discharge manifold and piston assemblies as described.
2. Remove both (M8) locking nuts from studs.
3. With soft mallet, tap inlet manifold loose from crankcase.
4. Place inlet manifold on pair of clearance blocks with crankcase side down and drive out seals.
5. Invert inlet manifold with *CRANKCASE SIDE UP*.
6. Lubricate circumference of new Prrrrm-A-Lube seals, position in manifold with *GARTER SPRING DOWN* and drive into place.
7. Examine sleeves for scoring or other damage before removing.
8. If worn, grasp sleeve with pliers and pull off.

NOTE: This procedure will mar the sleeve so use only if sleeve is to be replaced.






9. Remove o-ring and back-up rings from piston rod.

REASSEMBLY


1. Place barrier slinger on rod.
2. Lubricate new o-rings and back-up rings. Install first o-ring in the o-ring groove on the piston rod. Position back-up ring against the shoulder in front of the first o-ring, then the second o-ring. Be careful to avoid damaging the o-rings when slipping them over the piston rod threaded ends.
3. Immerse sleeve in oil carefully twist and push onto rod (machined counter bore end first).
4. Replace seal retainers.
5. Exercise caution when replacing inlet manifold, so the inlet seals are not damaged by the threaded rod ends.
6. Replace locking nuts on studs.
7. Reassemble piston assemblies and discharge manifold as described.

Consult factory for your local distributor for crankcase servicing.

DISMANTLING CAT PUMP



Pumping Section Cut-away



SERVICE KITS

078-001 Cup Kit, BobCat

- 3 Cup
- 6 O-Ring, Cylinder
- 3 Cotterpin
- 1 Instruction Sheet
- 1 Cup Inserter

078-004 Hot Cup Kit, AquaCat

- 3 Cup
- 6 O-Ring, Cylinder
- 3 Cotterpin
- 1 Instruction Sheet
- 1 Cup Inserter

078-003 Seal Kit

- 3 Prrrrm-A-Lube Seal
- 3 Cotterpin
- 2 Abrasive Paper
- 1 Instruction Sheet

30431 Sleeve and Seal Kit

- 3 Prrrrm-A-Lube Seal
- 3 Barrier Slinger
- 3 Cotterpin
- 3 Sleeve
- 6 O-Ring, Sleeve
- 1 Instruction Sheet


30686 Valve Kit

- 3 Valve Spring Retainer
- 3 Valve Spring
- 3 Valve
- 3 Valve Seat
- 3 O-Ring, Cylinder
- 1 Instruction Sheet

30860 Piston Kit, BobCat

- 6 O-Ring, Cylinder
- 3 Back-Up Ring, Cylinder
- 3 Bac-Cup Piston
- 3 Bac-Cup Ring
- 3 Cup
- 3 Piston Spacer
- 3 Piston Retainer
- 3 Conical Washer (M6)
- 3 Nut (M6)
- 3 Cotterpin
- 3 Inlet Valves
- 1 Instruction Sheet

PISTON MODEL 290 Exploded View



PARTS LIST MODEL 290

ITEM	PART NO.	DESCRIPTION	QTY.
1	20285	O-Ring (Buna-N)	1
2	44274	Crankcase	1
3	156-008	Stud (M8 x 82)	2
4	097-004	O-Ring, oil filler cap	1
5	027-007	Oil filler cap	1
8	43340	O-Ring, crankcase cover	1
9	43339	Crankcase cover	1
10	074-021	Bubble oil gauge	1
11	23170	O-Ring, drain plug	1
12	25625	Drain plug	1
15	92520	Sems comb head screw (M6 x 20)	6
16	43804	Crankshaft	1
17	14487	Rearing	2
18	147-005	Oil seal (Buna-N)	2
19	097-007	O-Ring, oil seal case	2
20	041-021	Oil seal case	2
21	92519	Sems comb head screw (M6 x 16)	8
23	101799	Connecting rod	3
24	101800	Piston rod	3
25	16948	Piston pin	3
26	20017	Seal washer	3
27	147-006	Oil seal	3
28	25327	Barrier slinger	3
29	097-008	O-Ring, sleeve	3
	28771	O-Ring, sleeve (Viton)	3
30	29003	Back-up ring, Sleeve (Teflon)	3
31	29614	Sleeve (29743 Unchromed)	3
32	26854	Seal washer	3
33	138-001	Seal retainer	3
34	25128	Inlet manifold	1
	25635	Inlet manifold - stainless steel	1
35	147-008	Prrrrm-A-Lube seal	3
35	30325	Prrrrm-A-Lube seal (Viton)	3

ITEM	PART NO.	DESCRIPTION	QTY.
38	27004	Inlet valve	3
39	30543	Bac-Cup piston	3
40	097-025	Bac-Cup ring (Teflon)	3
41	044-001	Cup (Viton)	3
	43474	Bac-Cup assembly	3
39-41	078-001	BobCat cup kit	
39-41	078-004	AquaCat cup kit	1
42	27983	Piston spacer	3
43	27002	Piston retainer	3
44	27006	Conical washer - s/s (M6)	3
45	27000	Nut - s/s (M6)	3
46	14158	Cotterpin	3
47	045-004	Cylinder (43834 Unch)	3
48	097-012	O-Ring, cylinder (Buna-N)	6
	11377	O-Ring, cylinder (Viton)	6
49	097-024	Bac-Cup ring, cylinder	3
50	090-005	Discharge manifold	1
	25634	Discharge manifold - s/s	1
51	43442	Valve spring retainer	3
52	43360	Valve spring	3
53	43723	Valve	3
54	43434	Discharge valve seal	3
56	81109	Hex nut (M8)	2
57	101804	Hex flange nut (M8)	2
58	108-003	Shaft protector	1
Electric Clutch Assembly			
59	152-005	Tapered sleeve	1
60	077-005	Key, electric clutch	1
61	036-005	6" electric clutch	1
62	143-084	8-30 mm socket head screw	1
63	174-004	Flat washer (5/16 US)	1
64	174-018	Lock washer (5/16 US)	1

CAT PUMP TROUBLE SHOOTING GUIDE

PROBLEM: Pulsation

Cause

Debris in discharge valves of pump.

Worn Prrrrm-A-Lube seals.

Excessive temperature.

Solution

Clean or replace discharge valves.

Replace.

Check pump solenoid.

PROBLEM: Low pressure

Cause

Worn nozzle.

Belt slippage.

Air leak in inlet plumbing.

Relief valve stuck, partially plugged or improperly adjusted; valve seat worn.

Inlet suction strainer clogged or improper size.

Worn piston assembly. Abrasives in pumped fluid or serve cavitation. Inadequate water supply.

Fouled or dirty inlet or discharge valves.

Leaky discharge hose.

Solution

Replace nozzle of proper size.

Tighten or replace; use correct belt.

Dismantle, reseal, and reassemble.

Clean and adjust relief valve; check for worn and dirty valve seats. Kit available.

Clean. Use adequate size. Check more frequently.

Install proper filter. Suction at inlet manifold must be limited to lifting less than 20 feet of water or -8.5 PSI vacuum.

Clean inlet and discharge valve assemblies.

Replace worn valves, valve seats.

Replace discharge hose.

PROBLEM: Pump runs extremely rough, pressure is very low

Cause

Restricted inlet or air entering the inlet plumbing.

Inlet restrictions and/or air leaks. Damaged cup or stuck inlet or discharge valve.

Worn inlet manifold seals. Prrrrm-A-Lubes.

Solution

Proper size inlet plumbing; check for air tight seal.

Replace worn cup or cups, clean out foreign material, replace worn valves.

Replace worn seals.

PROBLEM: Cylinder O-Rings blown next to discharge manifold

Cause

Pressures in excess of rated PSI.

Warped manifold. Freezing.

Solution

Check for plugged nozzle, closed valves or improperly adjusted bypass valve.

Replace manifold.

PROBLEM: Leakage at the cylinder O-Rings at the discharge manifold and black, powdery substance in the area of the O-Ring

Cause

Loose cylinders. Cylinder motion caused by improper torque on the discharge manifold.

Solution

Retighten. Do not tighten too much or the ears of the manifold will be bowed, causing looseness in the center cylinder.

PROBLEM: Water leakage from under the inlet manifold

Cause

Worn inlet manifold seals. Prrrrm-A-Lube. Leaking sleeve O-Ring.

Solution

Install seals. If piston rod sleeves are scored, replace sleeves and sleeve O-Rings.

PROBLEM: Oil leak between crankcase and pumping section

Cause

Worn crankcase piston rod seals.

Solution

Replace crankcase piston rod seals.

PROBLEM: Oil leaking in the area of the crankshaft

Cause

Worn crankshaft seal or improperly installed oil seal.

Bad bearing.

Solution

Remove oil seal retainer and replace damaged gasket and/or seals.

Replace bearing.

(continues, next page)

CAT PUMP TROUBLE SHOOTING GUIDE

PROBLEM: Excessive play in the end of the crankshaft pulley

Cause

Worn ball bearing from excessive tension on drive belt.

Solution

Replace ball bearing. Property tension belt.

PROBLEM: Water in crankcase

Cause

May be caused by humid air condensing into water inside the crankcase.

Solution

Change oil at 3 month or 500 hour intervals using Cat pump crankcase oil (other approved oil every month or 200 hours).

Leakage of manifold inlet seals and/or piston rod sleeves O-Ring.

Replace seals, sleeves and O-Rings.

PROBLEM: Oil leaking from underside of crankcase

Cause

Worn crankcase piston rod seals.

Solution

Replace seals, sleeve and O-Rings.

PROBLEM: Oil leaking at the rear portion of the crankcase

Cause

Damaged or improperly installed oil gauge or crankcase rear cover O-Ring, and drain plug O-Ring.

Solution

Replace oil gauge or cover O-Ring, and drain plug O-Ring.

PROBLEM: Oil leakage from drain plug

Cause

Loose drain plug or worn drain plug O-Ring.

Solution

Tighten drain plug or replace O-Ring.

PROBLEM: Loud knocking noise in pump

Cause

Pulley loose on crankshaft.

Solution

Check key and tighten set screw.

Broken worn bearing.

Replace bearings.

PROBLEM: Frequent or premature failure of the inlet manifold seals

Cause

Scored rods or sleeves.

Solution

Replace rods and sleeves.

Over pressure to inlet manifold.

Reduce inlet pressure per instructions.

PROBLEM: Short cup life

Cause

Abrasive material in the fluid being pumped.

Solution

Install proper filtration on pump inlet plumbing.

Excessive pressure and/or temperature of fluid being pumped.

Check pressures and fluid inlet temperature; be sure they are within specified range.

Over pressure of pumps.

Reduce pressure.

Running pump dry.

Do not run pump without water.

Front edge of piston sharp.

Replace with new piston.

PROBLEM: Strong surging at the inlet and low pressure on the discharge side

Cause

Foreign particles in the inlet or discharge valve or worn inlet and/or discharge valves.

Solution

Check for smooth lap surfaces on inlet and discharge valve seats. Discharge valve seats, and inlet valve seats may be lapped on a very fine oil stone; damaged cups and discharge valves cannot be lapped but must be replaced.

VACUUM SYSTEM

INFORMATION

The vacuum blower incorporated in this machine is a positive displacement lobe type, manufactured by Cooper Industries. The performance and life of this unit is greatly dependent on the care and proper maintenance it receives.

Because of the close tolerances between the lobes and housing of the vacuum blower, solid objects entering the inlet will damage the internal lobes, gears and bearing or direct drive coupler.

To prevent this, a stainless steel filter screen has been placed at the vacuum inlet inside the vacuum recovery tank. This stainless steel screen is finger tight and should be removed for cleaning weekly.

CAUTION

When machine is being run for test purposes and the vacuum inlet on top of machine is open, caution should be used.


To protect the vacuum blower from overloading and damaging itself, there is a vacuum relief system installed on the vac tank. When the vacuum tank inlet is completely sealed off, a maximum of 12 HG will be attained. A hole on the top blower pipe elbow acts as the lubrication point. At the end of each day, LPS 1 or Pennzguard should be sprayed in before shutting down the machine. See blower lubrication illustration. If you fail to lubricate the vacuum blower daily, rust deposits and moisture will decrease the life of the vacuum blower.

Read the vacuum blower manual carefully for proper oil change and grease application. The maintenance log may differ slightly from the manual, but the truck-mounted carpet cleaning machine application is very demanding of the vacuum blower and therefore it should be maintained more regularly.

CAUTION

NOTE: Vacuum tank is protected from overflowing by a vacuum tank, float kill switch. This switch is not activated by foam, only by liquid.

Vacuum Flow




VACUUM TANK FILTER BAGS


HydraMaster filter bags are designed to trap all of the lint, that would normally collect at the bottom of your vacuum tank. The use of these bags, if emptied at the end of each job, will eliminate the build-up of much of the debris in the tank. The drawstring top of these bags is designed to be tied to the incoming dirty water inlet in the vacuum tank.

To reorder bags use part number 049-028.

Vacuum Tank Filter Bags



Blower Lube Port



Spray lubricant into blower lube port for 3 to 5 seconds, then immediately shut off machine. Use only LPS 1 moisture displacing lubricant.

VACUUM BLOWER TROUBLE SHOOTING GUIDE

PROBLEM: Loss of pressure

<u>Cause</u>	<u>Solution</u>
Collapsed vacuum hose between blower and vacuum tank.	Remove and replace hose. NOTE: A special reinforced hose is required for replacement.
Clogged stainless steel liner.	Remove and clean or replace stainless steel filter.
Defective vacuum tank seal.	Remove and replace vacuum tank seal.
Defective or "open" vacuum tank dump valve.	Close valve. Replace valve.
Fractured weld on vacuum tank.	Re-weld as required or replace tank.
Collapsed or kinked vacuum hose.	Reshape hose if possible and/or eliminate kinks.
Plugged vacuum hose.	Remove obstructions by reversing the vacuum hose.
Restriction in cleaning tool.	Remove obstruction.
Worn end plates or lobes in vacuum blower.	Replace worn components. NOTE: Must be accomplished by a qualified technician.
Defective relief valve.	Inspect and replace if necessary.

PROBLEM: Blower is seized

<u>Cause</u>	<u>Solution</u>
Rust.	Spray rust dissolving lubricant onto lobes to emulsify rust and attempt to rotate vacuum lobes.
Foreign matter.	Dismantle and remove foreign matter and repair as required. NOTE: Dismantling must be accomplished by qualified technician.
<i>Note: The above mentioned, rust, foreign matter and seizing are often caused from foam traveling through the blower.</i>	

PROBLEM: Noise in vacuum blower

<u>Cause</u>	<u>Solution</u>
Worn gears.	Remove and replace gears. NOTE: Replacement of gears must be accomplished by qualified technician. Timing of vacuum blower has been changed due to worn components. NOTE: Replacement of components must be accomplished by qualified technician.
Lack of lubrication. NOTE: Permanent damage may have resulted from lack of lubrication.	Lubricate as specified by applicable vacuum blower manual. See Table of Contents.
Worn bearings.	Remove and replace bearings as required. NOTE: Must be accomplished by qualified technician.
Debris and/or foreign material build-up. NOTE: A stainless steel filter is provided in vacuum inlet located in vacuum blower components.	Dismantle vacuum blower and remove foreign material. NOTE: Dismantling should be accomplished by qualified technician only. Replacement of worn parts is necessary.
Loose or missing mounting bolts.	Tighten or reinstall mounting bolts.

VACUUM BLOWER WARRANTY

FULLER warrants products of its manufacture to be free from defects in material and workmanship if properly installed, maintained, and operated under normal conditions with competent supervision.

No person, agent, representative or dealer is authorized to give any warranties on behalf of FULLER nor to assume for FULLER any other liability in connection with any of FULLER'S products.

This warranty shall extend for two (2) years from date of installation provided this equipment has been put into service within six months after shipment from the FULLER factory. If repairs or replacements are made by the Purchaser without FULLER'S prior written consent, FULLER'S warranty shall cease to be in effect. No allowance will be granted for any repairs or alterations made by the Purchaser without FULLER'S prior written consent.

Machinery, equipment and accessories furnished by FULLER, but manufactured by others, are warranted only to the extent of the original manufacturer's warranty to FULLER.

FULLER agrees at its option to repair at the point of shipment or to replace without charge f.o.b. point of shipment, any part or parts of products of FULLER'S manufacture, which within the specified warranty period shall be proved to FULLER'S satisfaction to have been defective when shipped, provided the Purchaser promptly notifies FULLER, in writing, of such alleged defect.

FULLER'S liability to Purchaser, whether in contract or in tort arising out of warranties, representations, instructions, or defects from any cause shall be limited to repairing or replacing of the defective part or parts as aforesaid, f.o.b. point of shipment.

No liability whatsoever shall attach to FULLER until said products have been paid for. EXCEPT AS STATED IN THIS SECTION AND IN THE PRECEDING SECTION TITLED 'WARRANTY' AND EXCEPT AS TO TITLE, THERE ARE NO GUARANTEED OR WARRANTIES OF MERCHANTABILITY, FITNESS, PERFORMANCE OR OTHERWISE, EXPRESS, IMPLIED OR STATUTORY, AND FULLER SHALL HAVE NO LIABILITY FOR CONSEQUENTIAL, INCIDENTAL OR OTHER DAMAGES, HOWSOEVER CAUSED.

DATE INSTALLED _____ MODEL _____ SERIAL # _____

FULLER COMPANY 2966 East Victoria Street Compton, California 90224

VACUUM BLOWER LUBRICATION

At the gear end the timing gear teeth are lubricated by being partially submerged. The gear teeth serve as oil slingers for gear end bearings. At the drive end of the bearings are grease lubricated.

FILLING PROCEDURE

Remove square head vented oil fill plug (A) on gear end. Remove oil level plug (B) located in the head plate. Fill gear case until oil drips out of the oil level hole (B). Use lubricants as listed. Add fresh oil as required to maintain proper level. The oil should be drained, flushed and replaced every 300 hours or more frequently if inspection so indicates. The oil drain plug is at (C).

NOTE: Older units may have the oil fill level and drain holes located in the cast iron gear case instead of in the head plate. Bearings on drive end of blower require grease lubrication every 100 hours of operation. Bearings which require grease lubrication will have a grease fitting (D) at each bearing. When regreasing, the old grease will be forced out of the vents during operation. To prevent damage to seals, these vents must be kept open at all times.


Vacuum Blower Motor Lubrication

BLOWER DISCHARGE TEMPERATURE	OIL GRADE U.S.A.*	OIL VISCOSITY CENTISTOKES @ 40° C
-40° to 32° F (-40° to 0° C)	SAE 10W	45
32° to 100° F (0° to 38° C)	SAE 20	100
100° to 275° F (38° to 135° C)	SAE 40	200
over 275° F (135° C)	SAE 50	250

*In applications with extreme variations in ambient temperature a 20W-50W multiple viscosity oil is recommended.


FOR GREASE LUBRICATED BEARINGS
Service every 500 hours of operation

BLOWER DISCHARGE TEMPERATURE	TYPE GREASE
-40° to 275° F (-40° to 120° C)	No. 2 Bearing Grease



VANGUARD OHV

OPERATING AND MAINTENANCE INSTRUCTIONS FOR MODEL SERIES 303400 (16 HP)



INTERNATIONAL SYMBOLS USED IN THIS SECTION OF MANUAL



.....Read Operator's Manual



.....Warning/Caution



.....Oil



.....Fuel



.....Air Cleaner

IN THE INTEREST OF SAFETY



*BEFORE STARTING ENGINE, READ AND UNDERSTAND
THE "OPERATING AND MAINTENANCE INSTRUCTIONS."*



*THIS SYMBOL MEANS WARNING OR CAUTION.
DEATH, PERSONAL INJURY AND/OR PROPERTY DAMAGE
MAY OCCUR UNLESS INSTRUCTIONS ARE FOLLOWED
CAREFULLY.*

WARNING



WARNING: DO NOT

1. DO NOT run engine in an enclosed area. Exhaust gases contain carbon monoxide, an odorless and deadly poison.
2. DO NOT place hands or feet near moving or rotating parts.
3. DO NOT store, spill, or use gasoline near an open flame, or devices such as a stove, furnace, or water heater which use a pilot light or devices which can create a spark.
4. DO NOT refuel indoors where area is not well ventilated. Outdoor refueling is preferred.
5. DO NOT fill fuel tank while engine is running. Allow engine to cool for 2 minutes before refueling. Store fuel in approved safety containers.
6. DO NOT remove fuel tank cap while engine is running.
7. DO NOT operate engine when smell of gasoline is present or other explosive conditions exist.
8. DO NOT operate engine if gasoline is spilled. Move machine away from the spill and avoid creating any ignition until the gasoline has evaporated.
9. DO NOT transport engine with fuel in tank.
10. DO NOT smoke when filling fuel tank.
11. DO NOT choke carburetor to stop engine. Whenever possible, gradually reduce engine speed before stopping.
12. DO NOT run engine at excessive speeds. This may result in injury.
13. DO NOT tamper with governor springs, governor links or other parts which may increase the governed engine speed.
14. DO NOT tamper with the engine speed selected by the original equipment manufacturer.
15. DO NOT check for spark with spark plug or spark plug wire removed. Use an approved tester.
16. DO NOT crank engine with spark plug removed. If engine is flooded, place throttle in "FAST" position and crank until engine starts.
17. DO NOT strike flywheel with a hard object or metal tool as this may cause flywheel to shatter in operation. Use proper tools to service engine.
18. DO NOT operate engine without a muffler. Inspect periodically and replace, if necessary. If engine is equipped with muffler deflector, inspect periodically and replace, if necessary, with correct deflector.
19. DO NOT operate engine with an accumulation of grass, leaves, dirt or other combustible material in the muffler area.
20. DO NOT use this engine on any forest covered, brush covered, or grass covered unimproved land unless a spark arrester is installed on the muffler. The arrester must be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on Federal lands.
21. DO NOT touch hot muffler, cylinder, or fins because contact may cause burns.
22. DO NOT run engine with air cleaner or air cleaner cover (or cover directly over carburetor air intake, if Sno/Gard engine) removed.

◆ WARNING ◆



WARNING: DO

1. ALWAYS DO remove the wire from the spark plug when servicing the engine or equipment TO PREVENT ACCIDENTAL STARTING. Disconnect the negative wire from the battery terminal if equipped with a 12 volt starting system.
2. DO keep cylinder fins and governor parts free of grass and other debris which can affect engine speed.
3. DO pull starter cord slowly until resistance is felt. Then pull cord rapidly to avoid kickback and prevent hand or arm injury.
4. DO examine muffler periodically to be sure it is functioning effectively. A worn or leaking muffler should be repaired or replaced as necessary.
5. DO use fresh gasoline. Stale fuel can gum carburetor and cause leakage.
6. DO check fuel lines and fittings frequently for cracks or leaks. Replace if necessary.

NOTE: Use Original Briggs & Stratton Service Replacement Parts when servicing your engine. Briggs & Stratton Authorized Service Centers carry a stock of such parts. The use of Briggs & Stratton Parts preserves the original design of your engine. Imitation replacement parts offer potential risk including the risk of personal injury. Contact any Briggs & Stratton Authorized Service Center for Original Briggs & Stratton Replacement Parts.


BEFORE STARTING

READ THE OPERATING INSTRUCTIONS OF THE EQUIPMENT THIS ENGINE POWERS.

OIL RECOMMENDATIONS

We recommend use of a high quality detergent oil *For Service SC, SD, SE, SF, or SG,* such as Briggs & Stratton high quality detergent 30 weight oil (part no. 100005), or 10W-30 weight oil (part no. 272001). Detergent oils keep the engine cleaner and retard formation of gum and varnish deposits. Use no special additives with recommended oils.

RECOMMENDED SAE VISCOSITY GRADES



- * Use SAE 30 oil in high temperature, high load applications.
- ** 10W-40 oil may be substituted if 10W-30 is not available.
- *** Use synthetic oil having 5W-20, 5W-30 or 5W-40 viscosity. If not available, a petroleum-based multi-grade oil may be used having 5W-20 or 5W-30 viscosity.

NOTE: Using multigrade oils (5W-20, 5W-30, 5W-40, and 10W-30) will increase oil consumption. Check oil level more frequently when using them.


TO FILL CRANKCASE WITH OIL

Place engine level. Clean area around oil fill. Remove dipstick. *POUR OIL SLOWLY.* Fill to FULL mark on dipstick. *DO NOT OVERFILL.*


NOTE: After starting engine, stop after 30 seconds. Check oil level and add if necessary. Without filter, oil capacity is approximately 1-1/2 qts. (48 ozs. or 1.42 ltrs). With oil filter, oil capacity is approximately 1-3/4 qts. (56 ozs. or 1.65 ltrs).

TO CHECK OIL LEVEL

Place engine level. Remove dipstick and wipe oil from it with clean cloth. Screw dipstick into tube until cap bottoms on tube. Remove and check oil level. Dipstick must be firmly screwed into tube when engine is running.



Engine Components



- | | |
|------------------------|---------------------------------|
| 1. Air Cleaner | 7. 12 Volt Electric Starter |
| 2. Fuel Shut-off Valve | 8. Model, Type and Code Numbers |
| 3. Carburetor | 9. Spark Plug |
| 4. Rewind Starter | 10. Valve Cover |
| 5. Blower Housing | 11. Fuel Tank (Optional) |
| 6. Oil Drain Plug | |



FUEL RECOMMENDATIONS

This engine will operate satisfactorily on any gasoline intended for automotive use. A minimum of 85 octane is recommended. **DO NOT MIX OIL WITH GASOLINE.**


Use clean, fresh, lead-free gasoline. We recommend the use of Briggs & Stratton Gasoline Additive, part no. 5041. Purchase fuel in quantity that can be used within 30 days. This will assure fuel freshness and volatility tailored to the season. Leaded gasoline may be used if lead-free is not available. Use of lead-free gasoline results in fewer combustion deposits and longer valve life.

NOTE: We **DO NOT** recommend the use of gasoline which contains alcohol, such as gasohol. However, if gasoline with alcohol is used, it **MUST NOT** contain more than 10 percent Ethanol and **MUST** be removed from the engine during storage. **DO NOT** use gasoline containing Methanol. See STORAGE INSTRUCTIONS (page 27).

◆ WARNING ◆

DO NOT REMOVE fuel cap while engine is running. DO NOT FILL fuel tank to point of overflowing. Allow approximately 1/4 in. (5mm) of tank space for fuel expansion.

Engine Components



- | | |
|------------------------|-----------------|
| 12. Fuel Pump | 15. Crankshaft |
| 13. Dipstick | 16. Oil Filter |
| 14. Exhaust Manifold 1 | 17. Air Cleaner |

CARBURETOR ADJUSTMENTS


Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude or load. Air cleaner and air cleaner cover must be assembled to carburetor when running engine.

TWIN CYLINDER CARBURETOR ADJUSTMENT IS UNIQUE. ADJUST CARBURETOR FUEL MIXTURE IN THE ORDER STATED AS FOLLOWS:

INITIAL ADJUSTMENT

Gently turn idle mixture screw clockwise until it just closes. Turning screw in too far may damage it. Then turn idle mixture screw 1-1/2 turns counterclockwise. This initial adjustment will permit the engine to be started and warmed up (approximately 5 minutes) prior to final adjustment.

Carburetor Adjustment Screws



FINAL ADJUSTMENT


Start engine and place equipment speed control in "IDLE" or "SLOW" position. Hold carburetor throttle lever against idle stop and adjust idle speed screw to obtain 1300 to 1500 RPM. Still holding throttle lever against idle stop, turn idle mixture screw slowly clockwise (lean) until speed just starts to slow and then slowly counterclockwise (rich) until engine just starts to slow. Finally, turn screw to midpoint between rich and lean.

Now adjust idle speed screw to obtain 1200 RPM, if governed idle spring is red, or 900 RPM, if governed idle spring is white. Release throttle lever.

If engine does not accelerate smoothly, readjust idle mixture screw approximately 1/8 turn counterclockwise (rich).

NOTE: Engines operated at altitudes of approximately 3000 to 5000 feet (900 to 1500 meters) or higher may require the installation of a high altitude carburetor main jet to achieve best engine performance. If erratic performance is observed, contact a Briggs & Stratton Authorized Service Center for a high altitude jet.

Governed Idle Spring



ENGINE MAINTENANCE

CAUTION

TO PREVENT ACCIDENTAL STARTING when servicing the engine or equipment, always remove spark plug wires from spark plugs. Disconnect negative wire from battery terminal, if equipped with 12 volt starting system.


CHECK OIL LEVEL REGULARLY: Check after each 8 hours of operation or daily. BE SURE OIL LEVEL IS MAINTAINED.

CHANGE OIL AS RECOMMENDED

Change oil after first 8 hours of operation. Thereafter, under normal operating conditions change oil after every 50 hours of operation or every season, whichever occurs first. Change oil every 25 hours if engine is operated under heavy load or at high ambient air temperatures. Remove oil drain plug and drain oil while engine is warm. Replace drain plug. Remove dipstick and refill with new oil of correct grade and weight. Replace dipstick.

CHANGE OIL FILTER

Replace oil filter after every 100 hours of operation or every season, which ever occurs first. Before installing new filter, lightly oil filter gasket with fresh clean engine oil. Screw filter on by hand until gasket contacts oil filter adapter. Tighten 1/2 to 3/4 turn more. Start and run engine at idle to check for oil leaks. Recheck oil level and add oil if required.



AIR CLEANER MAINTENANCE

SERVICE AIR CLEANER

Remove and service foam pre-cleaner every 25 hours or every season, whichever occurs first. Service paper cartridge every 100 hours or every season, whichever occurs first.

NOTE: Service air cleaner more often under dusty conditions.

ROUND DUAL ELEMENT

1. Unhook clips on both sides of air cleaner and remove cover.

To service pre-cleaner:

- Slide foam pre-cleaner off cartridge.
- Wash it in liquid detergent and water.
- Squeeze it dry in a clean cloth.
- Saturate it in engine oil. Wrap it in clean, absorbent cloth and squeeze to remove EXCESS oil.
- Reinstall pre-cleaner over cartridge.
- Reinstall air cleaner cover and reattach clips to sides of air cleaner body.

To service cartridge:

- Remove knob and cover plate.
- Remove cartridge and clean by tapping gently on flat surface.
- If very dirty, replace or wash in a non-sudsing detergent and warm water solution. Rinse thoroughly with water from inside out until water runs clear. Let cartridge dry thoroughly before using.


CAUTION

Petroleum solvents, such as kerosene, are not to be used to clean cartridge. They may cause deterioration of the cartridge. DO NOT OIL CARTRIDGE. DO NOT USE PRESSURIZED AIR TO CLEAN OR DRY CARTRIDGE.


d. Reinstall cartridge, cover plate, knob and pre-cleaner.

2. Reinstall air cleaner cover and reattach clips to sides of air cleaner body.

Round Dual Air Cleaner Element



Square Dual Air Cleaner Element



SQUARE DUAL ELEMENT

1. Loosen knob and remove cover assembly.
2. Remove cartridge and pre-cleaner from cover.

To service pre-cleaner:

- a. Wash pre-cleaner in liquid detergent and water.
- b. Squeeze it dry in a clean cloth.
- c. Saturate it in engine oil. Wrap it in clean, absorbent cloth and squeeze to remove all EXCESS oil.

To service cartridge:

- a. Clean by tapping gently on flat surface.
- b. If very dirty, replace or wash in a nonsudsing detergent and warm water solution. Rinse thoroughly with water from inside out until water runs clear. Let cartridge dry thoroughly before using.

◆ CAUTION ◆

Petroleum solvents, such as kerosene, are not to be used to clean cartridge. They may cause deterioration of the cartridge. DO NOT OIL CARTRIDGE. DO NOT USE PRESSURIZED AIR TO CLEAN OR DRY CARTRIDGE.

3. Reinstall pre-cleaner in cover with foam toward cover.
4. Reinstall cartridge in cover with tabs on cartridge in slots in cover.
5. Reinstall cover assembly on air cleaner body.

CLEAN ENGINE

Remove dirt and debris with a cloth or brush. Cleaning with a forceful spray of water is not recommended as water could contaminate the fuel system.

CLEAN ROTATING SCREEN (ELECTRIC START ENGINES) OR REWIND STARTER GARD

Brush grass, chaff and dirt from rotating screen or rewind starter gard daily (more often if needed) to prevent engine damage caused by overheating and/or overspeeding.

◆ CAUTION ◆


To assure smooth operation, keep governor controls and linkage clean and free of debris.

◆ CAUTION ◆

Periodically clean muffler area to remove all grass, dirt and combustible debris.

CLEAN COOLING SYSTEM


Grass, chaff or dirt may clog the rotating screen and the air cooling system. Every 100 hours or every season, whichever occurs first, remove the blower housing and clean the area shown to prevent overspeeding, overheating and engine damage. Clean more often if necessary.



CLEAN SPARK ARRESTER SCREEN

If engine muffler is equipped with spark arrester screen assembly, remove every 50 hours or every season for cleaning and inspection. Replace if damaged. Contact any Briggs & Stratton Authorized Service Center.

REPLACE SPARK PLUGS



Replace every 100 hours of operation or every season, whichever occurs first.


NOTE: Do not blast clean spark plugs. Spark plugs should be cleaned by scraping or wire brushing and washing with a commercial solvent.

◆ CAUTION ◆

Sparking cannot occur if wire terminal does not fit firmly on spark plug. Reform terminal if necessary.

REPLACE FUEL FILTER

Replace In-Line filter every season or more often if required. Contact any Briggs & Stratton Authorized Service Center for correct replacement.



ENGINE MAINTENANCE SCHEDULE

Follow the hourly or calendar intervals, whichever occur first. More frequent service may be required.

MAINTENANCE OPERATION	Every 8 Hours or Daily	25 Hours or Weekly	50 Hours or Monthly	100 Hours or Every Season	Yearly
Check Oil Level	●				
Change Oil †			● Note 2		
Change Oil Filter				●	
Service Air Cleaner Pre-Cleaner		● Note 1			
Service Air Cleaner Cartridge				● Note 2	
Inspect Spark Arrester (Optional Accessory)			●		
Clean Cooling System				● Note 2	
Replace In-Line Fuel Filter					●
Replace Spark Plug				●	
Check Valve Clearance					●

† Change oil after first 8 hours, then after every 50 hours or every season.

Note 1: Change oil every 25 hours when operating under heavy load or in high ambient temperatures.

Note 2: Clean more often under dusty conditions or when airborne debris is present.

BRIGGS & STRATTON AUTHORIZED SERVICE CENTERS ARE READY TO SERVE YOU AND COMMITTED TO QUALITY SERVICE.

GENERAL INFORMATION ABOUT ENGINE

This is a twin cylinder, overhead valve, air cooled engine. All drilled/tapped holes and fasteners on this engine are ISO metric. However, where equipment attaches to engine, SAE standards apply.

On mobile equipment, this engine will operate satisfactorily at any angle at which operator and equipment can function safely.

MODEL SERIES 290400, 294400 & 303400

Bore	2.68 in. (68 mm)
Stroke	2.60 in. (66 mm)
Displacement	29.3 cu. in. (480 cc)
Horsepower	290400 12 HP @ 3600 RPM
Horsepower	294400 14 HP @ 3600 RPM
Horsepower	303400 16 HP @ 3600 RPM

MODEL SERIES 350400

Bore	2.83 in. (72 mm)
Stroke	2.76 in. (70 mm)
Displacement	34.7 cu. in. (570 cc)
Horsepower	18 HP @ 3600 RPM

NOTE: For practical operation, the horsepower loading should not exceed 85% of this rating. Engine power will decrease 3-1/2% for each 1,000 feet (305 m) above sea level and 1% for each 10° F (5.6°C) above 77° F (25°C).

TUNE-UP SPECIFICATIONS

DESCRIPTION	B & S PART NO.
Air Cleaner Pre-cleaner (round)	271271
Air Cleaner Cartridge (round)	394018
Air Cleaner Pre-Cleaner (square)	805113
Air Cleaner Cartridge (square)	805267
Air Cleaner Pre-cleaner (with fuel tank)	271794
Air Cleaner Cartridge (with fuel tank)	393957
Fuel Filter (without fuel pump)	298090
Fuel Filter (with fuel pump)	394358
Oil Filter	491056
Resistor Spark plug (Champion RC 12YC)	491055

NOTE: Walking fingers logo and "Yellow pages" are registered trademarks in various jurisdictions.

CLEARANCES	DIMENSION
Spark Plug Gap030 in. (.76 mm)
Intake Valve*004-.006 in. (.10-.15mm)
Exhaust Valve*004-.006 in. (.10-.15mm)

* Check when engine is cold.

In some areas, local law requires the use of a resistor spark plug to suppress ignition signals. If an engine was originally equipped with a resistor spark plug, be sure to use the same type of spark plug for replacement.

STORAGE INSTRUCTIONS

Engines to be stored over 30 days need to be protected or drained of fuel to prevent gum from forming in the fuel system or on essential carburetor parts.

1. For engine protection, we recommend the use of Briggs & Stratton Gasoline Additive, Part No. 5041, available from any Briggs & Stratton Authorized Service Center. Mix Additive with fuel in fuel tank or storage container. Run engine for a short time to circulate Additive through carburetor. Engine and fuel can be stored up to 24 months.

CAUTION

If Additive is not used or if engine is operating on gasoline containing alcohol, remove all fuel from tank and run engine until it stops from lack of fuel.

2. While engine is still warm, drain oil from crankcase. Refill with fresh oil.
3. Remove spark plugs and pour approximately 1 ounce (30 ml) of engine oil into each cylinder. Replace spark plugs and crank slowly to distribute oil.
4. Clean dirt and chaff from cylinders, cylinder head fins, blower housing, rotating screen and muffler areas.

SERVICE & REPAIR INFORMATION

If service or repair is needed, contact a Briggs & Stratton Authorized Service Center. To serve you promptly and efficiently, a Service Center will need model, type and code numbers from your engine.



Your nearest Service Center may be located in the "Yellow Pages™" directory under "Engines, Gasoline," "Gasoline Engines," or similar category. You may also locate the Service Center in your mailing zip code area by telephoning **1-800-233-3723**. There are over 30,000 Authorized Service Centers worldwide available to serve you.

Authorized Service Centers carry a stock of Original Briggs & Stratton Service Replacement Parts and are equipped with special service tools. Ask for and use ONLY original Briggs & Stratton Service Replacement Parts which preserve the original design of your engine. Imitation replacement parts offer potential risks in internal construction as well as fit, finish and warranty back-up. Trained mechanics offer expert service. Major engine repairs require proper tools and a thorough knowledge of internal combustion engine repair procedure.

Briggs & Stratton publishes illustrated shop manuals, parts lists and owner's manuals for every engine it manufactures. To receive a list of available publications, write to Briggs & Stratton Corporation, P.O. Box 1144, Milwaukee, WI 53201, Attention: Service Division. The shop manual shown here includes "Theories of Operation," common specifications and detailed information covering the adjustment, tuneup and repair of Briggs & Stratton OHV, twin cylinder, 4 cycle engines and is available from any Briggs & Stratton Authorized Service Center. You can also order directly from the factory at the above address. Request manual, Part No. 272144.



Part No. 272144

ABOUT THE WARRANTY ON THE VANGUARD ENGINE

If warranty service is needed, contact your nearest Authorized Briggs & Stratton Service Center. For prompt attention, your Center will need to know the engine model, type and code numbers, the trouble experienced and the total number of hours the engine was run.

BRIGGS & STRATTON WARRANTY COVERS ONLY DEFECTIVE MATERIAL AND/OR WORKMANSHIP.

Briggs & Stratton Corporation welcomes the opportunity to make justified warranty repairs by any of its Authorized Service Centers. In most instances, the requests for warranty repair are handled in a quick and routine manner. However, some requests for warranty are received which appear not justified. In these cases, though engine owners may not be aware of it, the premature failure of their engine was caused by abuse or neglect, or the equipment on which it was mounted, rather than the engine.

If you differ with the decision of your Service Center, investigation will be made to determine the applicability of warranty. Ask the Service Center to submit all supporting facts to the Factory for review. If the Factory decides that your claim is justified, you will be fully reimbursed for those items accepted as defective. To avoid misunderstanding which might occur between engine owners and Authorized Briggs & Stratton Service Centers, we list below some of the causes of engine failure that Briggs & Stratton warranty does not cover for repair or replacement.

LIMITED WARRANTY FOR VANGUARD ENGINES

"For two years from date of purchase, Briggs & Stratton Corporation will replace for the original purchasers, free of charge, any part, or parts of the engine, found upon examination by any Factory Authorized Service Center, or by the Factory at Milwaukee, Wisconsin, to be defective in material or workmanship or both. This is the exclusive remedy.

"For five years from date of purchase, Briggs & Stratton Corporation will replace for the original purchasers, free of charge, any part, or parts of the MAGNETRON® Ignition System (excluding the spark plug), found upon examination by any Factory Authorized Service Center, or by the Factory at Milwaukee, Wisconsin, to be defective in material or workmanship, or both, so as to result in the loss of ignition. This is the exclusive remedy.

"All transportation charges on parts submitted for replacement under this Warranty must be borne by purchaser. For warranty service contact your nearest Authorized Service Center as listed in the 'Yellow Pages' under 'Engines, Gasoline' or 'Gasoline Engines.'

THERE IS NOT OTHER EXPRESS WARRANTY. IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO ONE YEAR FROM PURCHASE AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED. LIABILITY FOR CONSEQUENTIAL DAMAGES UNDER ANY AND ALL WARRANTIES ARE EXCLUDED TO THE EXTENT EXCLUSION IS PERMITTED BY LAW.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation and exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction."

Briggs & Stratton Corporation

F.P. Stratton, Jr.
Chairman and Chief Executive Officer

WARRANTY PERIOD

ENGINESAll Vanguard and V/C engines.
CONSUMER USE*2 year-engine Lifetime**-Magnetron@ignition
COMMERCIAL USE*2 year-engine Lifetime**-Magnetron@ignition

* For purposes of this warranty policy, "consumer use" shall mean personal residential household use by the original retail consumer. "Commercial use" shall mean all other uses, including use for commercial, income producing or rental purposes. Once an engine has experienced commercial use, it shall thereafter be considered as a commercial use engine for purposes of this warranty policy.

** Lifetime limited warranty of the Magnetron ignition shall cover parts and labor for the first five (5) years from the date of purchase; thereafter only parts, "Lifetime" shall mean lifetime of the engine in the hands of the original purchaser.

*** Applies to equipment retailed in the U.S.A. and Canada. In all other countries, the warranty for CONSUMER USE is the same as COMMERCIAL USE.

NO REGISTRATION (WARRANTY) CARD IS NECESSARY TO OBTAIN WARRANTY ON BRIGGS & STRATTON ENGINES. SAVE YOUR PURCHASE RECEIPT. PROOF OF PURCHASE DATE WILL BE REQUIRED TO OBTAIN WARRANTY.

To avoid misunderstandings which might occur between engine owners and authorized Briggs & Stratton service accounts, we are listing some of the causes of engine failure, where repair or replacement is **NOT covered by Briggs & Stratton warranty.**

NORMAL WEAR:

Warranty will not cover repair where normal use has exhausted the life of a part or engine. Engines, like all mechanical devices, need periodic parts replacement and service to perform well. It should be remembered that the service life of any engine is dependent on the care it receives and the conditions under which it has to operate. Some applications, such as tillers, trash pumps, rotary mowers, are very often used in dusty or dirty conditions, which can cause what appears to be premature wear. Such wear, when caused by dirt, dust, spark plug cleaning grit or other abrasive material, which has entered the engine because of improper maintenance, is not covered by Warranty.

ABUSE OR NEGLECT:

1. Bent or broken crankshafts: Such damage is normally the result of abuse, such as striking a solid object with the cutter blade on a rotary lawn mower, and is not covered by Warranty.
2. Engine repairs required from the use of contaminated or stale fuel are not covered by Warranty. Such failures would include sticking valves, and carburetors and fuel pipes which are clogged by gum deposits which form through the use of stale fuel. Always use clean fresh regular gasoline.
3. Parts which are scored or broken because an engine was operated without sufficient lubricating oil, the proper grade of lubricating oil or contaminated lubricating oil are not covered by Warranty. Check oil level at least every five hours and refill when necessary. Change oil at recommended intervals.
4. Damage caused by overheating or overspeeding is not covered by Warranty. Overspeeding or overheating occurs if the cooling fins become plugged with dirt, grass or debris, or if an engine is operated in a confined area without sufficient ventilation. Clean fins on the cylinder, cylinder head and flywheel regularly.
5. Damage or wear caused by dirt which enters the engine because of improper air cleaner maintenance is not covered by Warranty. Clean and re-oil the air cleaner regularly.

6. Damage or wear caused by grit from blast cleaning spark plugs is not covered by Warranty. We do not approve of cleaning spark plugs on an abrasive blast cleaning machine, since grit can remain in the plug, and later enter the engine.
7. Warranty does not cover the tune-up or adjustment of an engine unless the need for such repair is the result of defects in material or workmanship or both. If equipment is assembled and adjusted by the owner, the engine operating and maintenance instructions are sufficiently clear to permit the average owner to make minor adjustments. Such minor adjustments are NOT covered by Warranty.
8. Broken parts, which result from excessive vibration caused by loose engine mounting, loose cutter blades, blade unbalance, improperly attaching equipment to engine crankshaft, overspeeding or abuse in operation, are not covered by warranty.
9. Repair or adjustment of associated parts or assemblies such as clutches, transmissions, remote controls, etc., which are not of Briggs & Stratton manufacture will not be covered by Briggs & Stratton Warranty.
10. Only ORIGINAL Briggs & Stratton parts, or parts approved by Briggs & Stratton may be covered by Warranty.

WARRANTY IS AVAILABLE ONLY THROUGH SERVICE CENTERS WHICH HAVE BEEN AUTHORIZED BY THE BRIGGS & STRATTON CORPORATION. YOUR NEAREST SERVICE CENTER IS LISTED IN THE YELLOW PAGES OF YOUR TELEPHONE DIRECTORY, UNDER "ENGINES, GASOLINE" OR "GASOLINE ENGINES."

ENGINE TROUBLE SHOOTING

See engine section of this manual beginning on page 21 to assist you in resolving engine related problems.

PROBLEMS:

ENGINE FAILS TO START

ENGINE RUNS ROUGH

ENGINE BACKFIRES

ENGINE FAILS TO ACCELERATE

ENGINE REDUCES SPEED TO LOW RPM UNDER LOAD

CAUSES AND/OR SOLUTION:

1. Loss of fuel.
 - A. Empty gas tank.
 - B. Plugged fuel line or filter.
 - C. Defective fuel pump (Replace with mfg. suggested replacement parts only).
 - D. Gas line kinked, crushed or quick disconnect inside the truck not connected.
2. Blown master fuse.
 - A. Electrical short.
 - B. Defective fuse.
3. Defective spark plugs.
 - A. Remove and replace.
 - B. Clean and regap.
4. Defective spark plug wires.
 - A. Spark plug wires along with many others may, at certain points come in contact with heated parts (exhaust manifold) or abrasive parts (sharp metal, teflon hose). This may be taken into consideration for electrical shorts.
 - B. Remove and replace ignition module.
5. Low compression.
 - A. Defective valve.
 - B. Stuck valve.
 - C. Worn compression rings.
 - D. Defective piston.
6. Float switch in recovery tank inoperative.

NOTE: Temporary repair permits disconnection of float switch wire between tank and machine. Continued operation with this condition will compromise vac blower.

 - A. Switch stuck on upright position by foreign material.
 - B. Defective float switch.
7. Engine will not turn over.
 - A. Dead battery.
 - B. Loose terminal connection on battery or ignition switch.
 - C. Defective starter.
 - D. Seized engine or blower.

8. Defective Carburetor or gas leakage.
 - A. Clean carb.
 - B. Replace carb.
 - C. Choke locked in closed position.

◆ CAUTION ◆

D. When replacing fuel pump insure that it is the same pressure rating recommended by manufacturer.

9. Improperly adjusted carb.

NOTE: A comprehensive manual is available and defines necessary adjustments.

 - A. Incorrect air mixture ratio adjustment.
 - B. Incorrect float level adjustment.
10. Carbon build-up in cylinders.

NOTE: Carbon build-up can be minimized by using unleaded regular gas. Should carbon removal be necessary, reinstall heads with new gaskets.

 - A. Carbon build-up may be excessive if carb, or valves are improperly adjusted, engine RPM too low, improper spark plug gap.
 - B. Remove cylinder heads and eliminate carbon build-up with wire brush.
11. Incorrect ignition module air gap.
 - A. Regap ignition module to specifications.
12. Dirty air cleaner.
 - A. If exhaust gaskets do not seat properly or heat exchanger gasket is bad, exhaust may heat and melt the air cleaner requiring much clean-up repair.
13. Clogged fuel filter.
 - A. Remove and replace.
14. Low oil level or malfunctioning oil pump.
 - A. Oil pressure sensors can be installed on the engine. This will eliminate many problems which may occur.
15. Vacuum tank full.
 - A. Empty vacuum tank.

ELECTRICAL SYSTEM

The entire electrical system operates on 12 volts DC which is provided by a battery. Battery levels are sustained by a 16 amp alternator designed with the engine.

NOTE: When new battery is installed insure it is properly charged before installation or damage to the charging regulator may occur.

PROBLEM: Low battery voltage

Cause

- Defective battery.
- Corroded battery terminals.
- Low battery fluid.
- Loose wiring within electrical system.
- Electrical short in wiring system.
- Poor ground connection.

Solution

- Remove and replace.
- Clean terminals and battery posts.
- Add water to appropriate level.
- Examine all terminal connections and verify that they are secure.
- Examine electrical systems for bare wires.
- Examine terminal and remove corrosion if necessary.

PROBLEM: Inoperative hour meter

Cause

- Time is not advancing correctly.


Solution

Verify 12 volt DC is available at the hour meter with the ignition switch turned on. This can be accomplished with a volt meter or a test lamp.

Remove and replace hour meter if 12 volt is available.

A nylon gear within the clock may have been jammed due to sudden jolt of the machine or truck. You may try simply tapping on the meter to try to free the nylon gear.

Electrical Diagram



* Indicates components found on AquaCat only

CORRECTION: ON ENGINE KILL RELAY, TERMINALS 85 & 87A ARE REVERSED.

FREEZE PROTECTION

BOBCAT

Any freezing of this machine is not covered by warranty and during the colder months of operation, careful protection should be of utmost concern.

THE FOLLOWING PRECAUTIONS ARE RECOMMENDED:

1. Run machine before leaving for the first job to insure nothing has frozen the night before, including hoses and wand.
2. Insulate the garden hose from the cold ground by running it through and extra 1-1/2 inch vacuum hose.
3. Leave truck doors closed until time cleaning begins, then open slightly for ventilation of air cooled engine.
4. On extremely cold days propane does not vaporize as quickly, therefore, venting the warm exhaust over to blow on the propane tank will stabilize the propane flow. (This is necessary if you notice a drop in heat or a low burning flame in the heater.)
5. In colder climates, insulating the tuck walls and floor boards will help protect the unit.
6. Don't procrastinate during the cleaning operation or the hot water solution line will also freeze on the ground. The solution line should be insulated in extremely cold climates.
7. Whenever possible, the truck and machine should be stored in a heated garage at night or over the weekend. If not possible, place a 1500 watt electric heater inside the truck, aimed directly at the machine. Never use a propane heater - it causes excessive moisture on the truck ceiling and the possibility of it going out is higher. If the machine and truck are left outside with a heater, you should first drain all possible water from the machine cleaning tools and hoses. (They freeze also.)

TO DRAIN THE MACHINE, FOLLOW THESE STEPS:

1. Before shutting off the machine, remove the chemical line from the chemical jug and place in a mixture of 50/50 anti-freeze and water. With the cleaning tool on, allow mixture to fill chemical system back to the chemical mix tank.
2. Loosen the petcock valve on your bypass drain hose and allow the water to drain thoroughly from the mix tank.
3. To remove the water from the heater and pump use the freeze guard kit which is a small air compressor that can be plugged into the dash board lighter in the truck, or air at the gas station. Using the correct connectors, first blow air into the high pressure solution male quick connect. This will force the water through the heater back through the pump and into the chemical mix tank to be drained out through the petcock valve to the ground.

Next, blow the air into the incoming water quick connect and force that water into the chemical mix tank to be drained out.

To be sure all water is out of the system, alternate between quick connectors several times.

8. **BE SURE IT'S PROTECTED!** Freezing will cause GRIEF, MONEY and DOWN-TIME. Don't mess with mother nature! Remember to close the petcock valve prior to next operation of your BobCat .

AQUACAT

Any freezing of this machine is not covered by warranty and during the colder months of operation, careful protection should be of utmost concern.

THE FOLLOWING PRECAUTIONS ARE RECOMMENDED:

1. Run machine before leaving for the first job to insure nothing has frozen the night before, including hoses and wand.
2. Insulate the garden hose from the cold ground by running it through and extra 1-1/2 inch vacuum hose.
3. Leave truck doors closed until time cleaning begins, then open slightly for ventilation of air cooled engine.
4. In colder climates, insulating the tuck walls and floor boards will help protect the unit.
5. Don't procrastinate during the cleaning operation or the hot water solution line will also freeze on the ground. The solution line should be insulated in extremely cold climates.
6. Whenever possible, the truck and machine should be stored in a heated garage at night or over the weekend. If not possible, place a 1500 watt electric heater inside the truck, aimed directly at the machine. Never use a propane heater - it causes excessive moisture on the truck ceiling and the possibility of it going out is higher. If the machine and truck are left outside with a heater, you should first drain all possible water from the machine cleaning tools and hoses. (They freeze also.)

TO DRAIN THE MACHINE, FOLLOW THESE STEPS:

1. Before shutting off the machine, remove the chemical line from the chemical jug and place in a mixture of 50/50 anti-freeze and water. With the cleaning tool on, allow mixture to fill chemical system back to the chemical mix tank.
2. Loosen the petcock valve on your bypass drain hose and allow the water to drain thoroughly from the mix tank.
3. Using the freeze guard hose provided with the machine, freeze guard the unit. First plug the rubber stopper into the outlet of the recovery tank. Then with the pressure regulating valve unscrewed, plug the other end of the freeze guard hose into the high pressure cleaning solution fitting on the front of the machine. Run the unit until the engine stops.
4. Open the mix tank drain valve and drain out the remainder of the water. The unit is now freeze guarded.

CLEANING AND CHEMICALS

PRECAUTIONS

Your mobile carpet cleaning plant has been engineered using the latest and most sophisticated technology available, to produce the finest carpet cleaning results possible. Despite this, however, it remains only a tool of the carpet cleaning trade, and it can produce only as good a job as the person operating it.


There are not short cuts to good carpet cleaning. It requires time, cleaning knowledge and the use of good chemicals.

The manufacturer recommends the use of spotting agents, and traffic lane cleaners prior to the actual cleaning of carpeting, as required.

The use of some chemicals through your mobile carpet cleaning plant can seriously damage the internal plumbing, high pressure pump and heater (Chemical such as concentrated acids, solvents, and some paint oil and grease removers w/high concentration of solvents).

The manufacturer recommends only the use of chemicals containing rust and corrosion inhibitors and water softening agents to prevent chemical build-up which may lead to component failure and warranty invalidation.

NOTE: At no time should a chemical solution with a pH of less than 7 or higher than 10 be used in the unit.




CLEANING STROKE PROCEDURE/OVER-WETTING

PURPOSE: To eliminate excess moisture remaining in the carpet fiber and the sawtooth appearance which results from diagonal movement of the cleaning tool on all types of carpet.

PROCEDURE: Always move the cleaning tool in smooth forward and backward strokes. Apply slight pressure to the forward stroke while the solution is injected into the carpet. When extracting (drying), apply firm pressure on the forward stroke to ensure a positive "lock" for the vacuum and minimize the "hopping" effect resulting on unsmooth carpet. During the forward and reverse strokes, movement to the right or left should only be accomplished at the extreme rear of the stroke. Overlapping is also important to ensure even application of solution to prevent saturation when cleaning wand is stopped twice at the same point at the rear of the cleaning stroke.

Failure to adopt this procedure can result in increased chance of "clean streaks", fiber shrinkage, brown out, and longer drying periods.



OVER-WETTING

Over-wetting is annoying to all concerned and sometimes leaves a bad impression of the cleaning process used.

THESE ARE SEVERAL AREAS THAT WILL CAUSE OVER-WETTING:

1. Too few vacuum strokes or improper saw tooth vacuum strokes as shown in the previous illustration.
2. Obstructed, kinked or cut hoses.
3. Vacuum tank drain valve left partially open.
4. Clogged vacuum blower filter or vacuum tank lid not sealing properly.
5. Cleaning a heavily foam-saturated carpet without defoamer. (We recommend crystal type.)

BOBCAT HEATING SYSTEM

INFORMATION

The propane heater incorporated in this equipment is a special design for use in the carpet cleaning industry. It's high pressure coils and thermostatic temperature control make it simple to operate and reliable. Once the desired temperature is set, the heater will then go 'on' and 'off' according to the water temperature within the heater. As water is used through the cleaning tool, cold water entering the heater will activate the thermostatically controlled propane valve thereby firing the heater to maintain a consistent flow of hot water. Once the cleaning wand is shut off and the flow of water through the heater stops, the heater will continue to burn until the set temperature is attained.

It is possible with this design that the flame may be on when the wand is off, likewise, it is possible the flame may be off when the wand is on.

CAUTION

This heater is designed to burn vapor propane gas only. Any liquid propane entering the heater may cause damage to the control valve on the heater. It will also cause improper burning and a soot build-up on the coils. Therefore, it is necessary to shut off the heater and close the valve at the tank between cleaning locations. Failure to do this allows sloshing liquid to enter the vapor feed line to the heater.

IMPORTANT: Overfilling of the propane tank will cause many problems. To avoid this, advise the attendant filling the tank **not to fill the tank over 90%**. When filling the tank, watch the 10% valve and immediately stop filling when white liquid starts spurting from the 10% valve. To prevent damage to the propane regulator, always close the valve on the tank before filling.

The propane regulator is pre-set at the factory at 6 oz. of propane. This reading is taken at the control valve on the heater. To prevent road dust and moisture from entering the propane regulator, keep the white plastic cover (supplied) on the regulator at all times.

To avoid restriction of air flow at base of heater, keep articles such as chemical containers, hose, boxes, etc. from within 18 inches of base of heater. **NOTE:** This restricted situation also creates an over rich condition which results in soot build-up.

IMPORTANT: If a new propane tank has been installed or hoses have been disconnected, air may enter propane hoses and must be purged prior to attempting to light the pilot burner. Should this condition exist, operator must depress the pilot button for 1-5 minutes and attempt to ignite the pilot light at 15 second intervals. A very slight hissing noise should be evident while performing this operation.

WARNING

Check heater for propane leaks regularly as loading and unloading hoses, tools, etc., may accidentally bump against heater fitting or pipes.

BOBCAT HEATER OPERATING INSTRUCTIONS

◆ CAUTION ◆

Heater must be filled with water prior to igniting.

A. TO START PILOT

1. Adjust thermostat control knob on Unitrol to desired setting (#3).
2. Adjust upper dial to pilot position (#1).
3. Depress pilot button (#2).
4. Depress sparking button to light pilot (#4).

IF PILOT FAILS TO LIGHT

- Is propane tank full?
- Is propane tank valve open?
- Has air been properly bled from propane line?
- Is ignitor system working?

WHEN PILOT LIGHTS

Wait ten seconds, depressing button manually, then release button.

◆ WARNING ◆

Always keep face away from main burner opening to avoid ignition flash burn.

B. TO LIGHT MAIN BURNER

1. Turn upper knob to "on" position. Flame will come on.

If you do not get the burner to flame, the pilot has expired. You must turn upper dial to "off" position. Do not attempt to re-light the pilot for 60 seconds. To light the main burner, repeat instructions as above (TO START PILOT), 1 through 4.

OR,

Water may already be at controlled temperature.

Flame will turn off when thermostat senses maximum temperature.

C. TO ACHIEVE PROPER CARPET CLEANING TEMPERATURE

1. Complete procedures A & B.
2. With 100' of hose, turn cleaning wand on for 2 minutes and the temperature should stabilize.
3. Once a constant temperature is established, turn cleaning wand 'off'. The flame on the heater burner should remain on for 10-15 seconds.
 - A. If the flame expires prior to 10 seconds, turn the thermostat dial to a higher reading, then repeat C 1-3.
 - B. If the flame remains lit after 15 seconds, turn the thermostat dial to a lower reading, then repeat C 1-3.

D. TO SHUT DOWN HEATER

1. Turn upper dial #1 to 'off' position.

◆ CAUTION ◆


2. Turn cleaning wand on for 3 to 5 minutes to cool heater core. If heater core is not cooled, it is possible that the heat retained in the core will cause boiling back into a chemical mix tank. This results in damages to Cat pump.

3. Close propane tank valve while wand is on and the heater is cooling.

PILOT BURNER ADJUSTMENT

1. Remove pilot adjustment cap #5.
2. Adjust pilot key to provide properly sized flame.
3. Replace pilot adjustment cap.

Allen head pipe plug #6 can be removed for manometer insertion to read propane ounces.



BOBCAT HEATER TROUBLE SHOOTING

PROBLEM: Excessive heat. Flames protruding outside the lower openings.

Cause/Solution

1. Maladjustment of propane regulator. **NOTE:** Propane regulators are factory preset and may be readjusted by authorized personnel.
 - A. Contact manufacturer to determine correct procedure.
 - B. Have your local propane dealer use a manometer at the Unitrol to reset the propane regulator to 7 oz. maximum.
2. Overfilled propane tank. Propane heaters are designed to operate on vapor propane only. Overfilling a propane tank allows liquid propane to enter all heater related components and permits an over-rich burning condition to occur. This condition usually requires the core to be cleaned of soot and carbon deposits. Cleaning is a messy, dirty job and very inconvenient, so do not let it happen to you!


PROBLEM: Pilot light

Cause/Solution


1. Pilot light will not ignite. **NOTE:** Do not use a needle or pin to clean pilot orifice—use compressed air or solvent only.
 - A. Verify propane reaching ignitor. **NOTE:** A kinked or crushed hose may impede propane flow.
 - B. Remove and clean orifice.
 - C. Verify ignitor spark is operating correctly.

CLEANING WAND


Wand Valve Assembly 169-005



Jet Assembly



Wand Assembly



WAND VALVE, JET & WAND PARTS LIST

ITEM	PART NO.	DESCRIPTION	QTY.
1	167-013	Trigger, cast Hydra hoe valve	1
2	094-009	Nut, 1/4 - 20 s/s nylock	2
3	107-130	Valve body - HydraMaster valve	1
4	052-152	1/4 Male comp. fitting - Hydra hoe	1
5	155-003	Spring, HydraMaster solution valve	1
6	097-011	O-Ring, HMaster solution valve cap	1
7	027-001	Cap, s/s HMaster solution valve	1
8	139-004	Ring, solution valve retaining	1
9	139-003	Ring keeper, HMaster solution valve	1
10	097-010	O-Ring, HM valve plunger - large	1
11	097-022	O-Ring, solution valve / llw mtr - small	1
12	107-129	Plunger, HydraMaster solution valve	1
13	052-050	440 Male quick connect w/iton	1
14	052-071	Nipple, 1/4 brass hex	1
15	052-082	Elbow, 1/4 brass 45 street	1
16	143-002	Screw, 1/4 - 20 x 1" HHC s/s	1
17	052-153	Brass stabilizer housing	1
18	186-001	Stabilizer	1
19	076-005	Jet, #6 s/s Hydra hoe, BobCat	1
	076-003	Jet, #4 s/s Hydra hoe, AquaCat	1
20	094-028	Nut, brass - jet assembly group	1
21	061-006	Handle, pressure guide wand	1
22	094-035	Nut, 5/16 - 18 s/s nylock half nut	2
23	143-012	Screw, 5/16 - 18 x 3/4" s/s HHC	2
24	173-006	Wand, s/s Hydra hoe - stock	1
25	082-001	Lips s/s Hydra hoe (2 piece set)	1
26	168-001	Tube, s/s Hydra hoe solution	1
27	061-007	Handle grip - Hydra hoe	1
Not shown in illustrations			
	154-001	Spacer, 1/4 x 5/16 - s/s sol. valve	5
	169-055	Valve assembly, s/s Hydra hoe	1
	143-004	Screw, 1/4 - 20 x 1.5" HHC s/s	2
	094-009	Nut, 1/4 - 20 s/s nylock	1

MAINTENANCE

PROCEDURES

To avoid costly repairs and down-time, it is imperative to develop and practice good maintenance procedures from the beginning. These procedures fall into daily, weekly, monthly and quarterly increments, and are outlined below. We have provided a maintenance log for your convenience on next page; it is recommended that you affix a copy of the log on the vehicle door near your unit for convenience and to serve as a maintenance reminder.

DAILY

Check engine oil level.
Inspect garden hose screen - clean as needed.
Visually inspect machine for loose wires, oil leaks, water leaks, etc.
Inspect recovery tank s/s filter and filter bag for tears, holes, etc. - clean, repair or replace as needed.
Lubricate blower with LPS-1 through blower inlet.

WEEKLY

Change engine oil. (50 hours of operation.)
Check engine air cleaner filter - clean as necessary.
Check high pressure pump oil - add as necessary.
Check drive coupler set screws - tighten as needed.
Check pump drive belt for wear - tighten as needed.
Check pump pulleys - tighten as needed.
Check fuel lines for wear/chafing.
Check all nuts and bolts - tighten as needed.
Check heater burner assy. union for tightness/leaks.
Clean vacuum tank thoroughly with high pressure washer.
Flush water and chemical system with 50/50 white vinegar solution.

MONTHLY

Grease blower bearing fittings.
Remove pressure Bypass Valve stem, grease cup and stem, reinstall.
Check water level in battery. Clean connections as needed.

QUARTERLY

Change oil in blower.
Check engine compression.
Check for combustion chamber carbon deposit.
Change spark plugs.

IMPORTANT:

Record date and machine hours in maintenance log.

AS REQUIRED: DESCALING

Scale deposits on the interior of heater tubes can cause a noticeable loss in heating performance. Deposits of this kind result from hard water deposits, excessive chemical use, improper chemicals, etc. The frequency with which descaling procedures are required will vary.

If your area has particularly hard water or you see evidence of deposits in the water system, you may have to descale monthly. To descale your system, add an appropriate descaler chemical to your mix tank, circulate in the heater, let stand, flush and repeat as necessary. Clean all screens and strainers, and check them frequently following descaling.

OVERALL CARE OF UNIT

MAINTAINING THE ORIGINAL APPEARANCE OF YOUR UNIT IS IMPORTANT FOR TWO REASONS:

1. It represents a big dollar investment for your cleaning business and its appearance should reflect that fact. A dirty machine is not professional!
2. Maintenance, trouble shooting, and repair is much easier to accomplish on a clean well maintained unit. Regular cleaning of the machine offers you an opportunity to visually inspect all facets of the machine and spot potential problems before they occur.

FOLLOWING MAINTENANCE IS RECOMMENDED BY THE MANUFACTURER AT THE FREQUENCY INDICATED.

AFTER EACH JOB:

Check recovery tank, s/s filter and filter bag as required.

DAILY:

Wipe machine down thoroughly with a damp cloth; flush recovery tank out thoroughly. Empty filter bag and inspect for rips, tears, etc. - replace as needed; remove, thoroughly clean and reinstall stainless steel filter screen in recovery tank; inspect and clean vacuum slot on cleaning wand; check wand head for sharp edges that could tear carpet - file down as needed; clean wand to maintain original appearance; wipe down vacuum and high pressure hoses as needed - visually inspect for cuts, etc.

WEEKLY:

Wipe down entire unit as needed - apply good coat of auto wax to all painted surfaces inside and out, and to control panel; thoroughly clean recovery tank using high pressure hot water (unit with optional high pressure cleaning gun may be used for this); remove stainless steel filter in recovery tank, thoroughly clean removing all lint build-up, inspect for damage and reinstall. Remove filter bag, thoroughly clean and reinstall - if torn, replace; empty chemical from chemical container, wash out thoroughly to remove any chemical build-up; inspect chemical feed line strainer and use 50% white vinegar/water solution to remove any chemical build-up; thoroughly clean wand and inspect for clogged jet, debris in vacuum slot and leaking fittings at valve. Apply light coat of auto wax to wand. Thoroughly clean vacuum and high pressure hoses including hose cuffs - inspect for wear or damage to hoses and quick connect fittings. Inspect garden hose connect/adaptor screen for debris, remove and clean thoroughly. Inspect all lines for wear or abrasions that may cause possible leaks.

MAINTENANCE LOG

DAILY CLEANING & INSPECTION

Engine oil - check Clean vac tank filter bag after every job
 Garden hose screen - clean Blower inlet - spray with LPS 1 after last job
 Machine - general inspection

WEEKLY SERVICE

MAX HRS	SERVICE	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS
25	BLOWER check oil level							
25	PUMP OIL check (top of sight gauge)							
25	BELTS & PULLEYS check tightness							
25	HIGH PRESSURE LINES check for chafing							
25	NUTS & BOLTS check tightness							
25	BATTERY LEVELS check							
25	VACUUM TANK clean							
25	WIRING check for chafing							
25	CHEMICAL SYSTEM flush w/vinegar							
50	ENGINE OIL CHANGE							

MONTHLY SERVICE

100	BLOWER grease bearing							
100	ENGINE AIR CLEANER clean							
100	BY PASS VALVE grease cup & stem							
100	OIL FILTER CHANGE							

QUARTERLY SERVICE (3 MONTHS)

300	BLOWER OIL change							
300	ENGINE compression							
300	SPARK PLUGS change							

MAINTENANCE LOG

DAILY CLEANING & INSPECTION

Engine oil - check Clean vac tank filter bag after every job
 Garden hose screen - clean Blower inlet - spray with LPS 1 after last job
 Machine - general inspection

WEEKLY SERVICE

MAX HRS	SERVICE	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS
25	BLOWER check oil level							
25	PUMP OIL check (top of sight gauge)							
25	BELTS & PULLEYS check tightness							
25	HIGH PRESSURE LINES check for chafing							
25	NUTS & BOLTS check tightness							
25	BATTERY LEVELS check							
25	VACUUM TANK clean							
25	WIRING check for chafing							
25	CHEMICAL SYSTEM flush w/vinegar							
50	ENGINE OIL CHANGE							

MONTHLY SERVICE

100	BLOWER grease bearing							
100	ENGINE AIR CLEANER clean							
100	BY PASS VALVE grease cup & stem							
100	OIL FILTER CHANGE							

QUARTERLY SERVICE (3 MONTHS)

300	BLOWER OIL change							
300	ENGINE compression							
300	SPARK PLUGS change							

MAINTENANCE LOG

DAILY CLEANING & INSPECTION

Engine oil - check Clean vac tank filter bag after every job
 Garden hose screen - clean Blower inlet - spray with LPS 1 after last job
 Machine - general inspection

WEEKLY SERVICE

MAX HRS	SERVICE	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS
25	BLOWER check oil level							
25	PUMP OIL check (top of sight gauge)							
25	BELTS & PULLEYS check tightness							
25	HIGH PRESSURE LINES check for chafing							
25	NUTS & BOLTS check tightness							
25	BATTERY LEVELS check							
25	VACUUM TANK clean							
25	WIRING check for chafing							
25	CHEMICAL SYSTEM flush w/vinegar							
50	ENGINE OIL CHANGE							

MONTHLY SERVICE

100	BLOWER grease bearing							
100	ENGINE AIR CLEANER clean							
100	BY PASS VALVE grease cup & stem							
100	OIL FILTER CHANGE							

QUARTERLY SERVICE (3 MONTHS)

300	BLOWER OIL change							
300	ENGINE compression							
300	SPARK PLUGS change							

MAINTENANCE LOG

DAILY CLEANING & INSPECTION

Engine oil - check Clean vac tank filter bag after every job
 Garden hose screen - clean Blower inlet - spray with LPS 1 after last job
 Machine - general inspection

WEEKLY SERVICE

MAX HRS	SERVICE	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS	DATE/HRS
25	BLOWER check oil level							
25	PUMP OIL check (top of sight gauge)							
25	BELTS & PULLEYS check tightness							
25	HIGH PRESSURE LINES check for chafing							
25	NUTS & BOLTS check tightness							
25	BATTERY LEVELS check							
25	VACUUM TANK clean							
25	WIRING check for chafing							
25	CHEMICAL SYSTEM flush w/vinegar							
50	ENGINE OIL CHANGE							

MONTHLY SERVICE

100	BLOWER grease bearing							
100	ENGINE AIR CLEANER clean							
100	BY PASS VALVE grease cup & stem							
100	OIL FILTER CHANGE							

QUARTERLY SERVICE (3 MONTHS)

300	BLOWER OIL change							
300	ENGINE compression							
300	SPARK PLUGS change							

HYDRAMASTER
Corporation

20309 64th Ave. W. / Lynnwood, WA 98036