
56113109 PEX HEATER REPAIR KIT

Pex 200, 500, 500-CSA

CONTENTS OF KIT



INSTALLATION INSTRUCTIONS


∆ WARNING!

UNPLUG THE UNIT FROM THE OUTLET PRIOR TO SERVICING OR PERFORMING ANY MAINTENANCE ON THE MACHINE AND WHEN REPLACING PARTS.

REMOVE HEAT EXCHANGER FOR REPAIR

- **See Figure 1:** Remove the (4) Socket Head Screws and Washers (A) from the back of the machine as shown.
- 2 The Recovery/Solution Tank is hinged at the bottom and can be tilted open to gain access to the Heat Exchanger (D) without having to remove the tanks.
- **3** Disconnect the Heat Exchanger spade connectors from the terminal block.
- 4 Disconnect the Hoses (B) from the Heat Exchanger (D) and loosen or remove the Hose Clamp (C) to remove the heat exchanger from the machine for repair.

FIGURE 1



INSTALL HEAT EXCHANGER REPAIR KIT

- 1 See Figure 2: To replace the Thermal Cutout Components (5, 6, 7, & 9) refer to the Instruction Sheet B item (12) from the Pex Heater Repair Kit 56113109.
- 2 Apply High Temp Electrical Tape (8) in the area shown before replacing the Thermal Cutout (6) so that it is installed under the thermal cutout before re-installing the heater wrap.
- 3 If you are replacing Thermostats (1, & 2) apply the Thermal Grease (4) to the mounting surface (E) prior to replacement using the (4) Screws (3).
- 4 To install the replacement Heater Harness (11), plug the spade connectors into the Thermostats (1, & 2). The nonterminated wire end attaches to the Thermal Cutout (6) using (1) Butt Connector (7) and Shrinktube (9) to assemble the harness to the newly replaced Thermal Cutout (6).
- 5 After repairing the Heat Exchanger (D) use the High Temp Tape (10) to reinstall the heater wrap foam to the outside of the heat exchanger as shown.
- 6 See Figure 1: Reinstall the repaired Heat Exchanger (D) back into the machine using the steps in reverse order.
- 7 Follow the instructions in the Operating The Machine section of your manual to test the repaired heat exchanger.

