

FabricMaster FF



UPHOLSTERY

RTU pH 11.0 Self
Neutralizes to 7.0
Straight to 1:4
Synthetic Upholstery
Fibers

Natural and Delicate Fabric Pre-spray for Gentle Cleaning

This neutral pH cleaning formula is specifically formulated for use on upholstery fabrics constructed with natural fibers, especially fine cottons, and fabrics with delicate, intricate weave textures and patterns.

This specialized formula is specifically designed to break down, dissolve, and emulsify the soils and spills most common to upholstery fabrics.



FabricMaster Fine Fabric recognizes the construction and texture of upholstery to be more delicate than carpet, so it does not use harsh solvents often used in carpet pre-sprays that can affect upholstery construction.

Specialized surfactants are used in this formula that do not over wet the fabric like typical surfactants, allowing you to clean the surface without soaking the back of the fabric. FabricMaster Fine Fabric Pre-spray contains the same stain removing additive that is in our famous SpotMaster Pro XP spotter, effectively removing many beverage spills without the need for special stain treatments. FabricMaster Fine Fabric Pre-spray can also be used to make a Haitian cotton shampoo formula by simply mixing in SpotMaster CSR.

Mixing Directions:

1. Vacuum fabric thoroughly before starting cleaning process
2. Always pre-test all cleaning solutions in an inconspicuous area for colorfastness prior to application.
3. For light to medium soil, mix one part FabricMaster FF with eight parts water (16 ounces of solution with gallon of water) into sprayer. For heavy soiling, do not dilute. Use straight.
4. To make a Haitian Cotton pre-spray, add 2 powder ounces of CleanMaster Spotmaster CSR to each mixed gallon of FabricMaster Fine Fabric Pre-spray.
5. Apply with hand-held pump up or trigger sprayer in an even, overlapping mist across the entire area of the fabric being cleaned.
6. Allow to dwell for 2-3 minutes. Be careful not to over spray or breathe mist.
7. Agitate with horsehair brush or bonnet mitt.
8. For best results extract area with CleanMaster RinseOut utilizing the HydraMaster DriMaster 3 Upholstery Cleaning Tool.
9. For faster drying, especially in humid environments, consider the use of an axial, centrifugal, or downdraft air mover after cleaning.

Available in: 1 Gallon; Case of 4 x 1 Gallon
Part # 950-220

HydraMaster
We've Got Your Back



www.hydramaster.com | 800.426.1301 | 425.775.7272
sales@hydramaster.com