



Date: 2/01/11

Dear HydraMaster Equipment Owner,

Included in this mailing is important information concerning your HydraMaster equipment. HydraMaster will at times correspond with you directly about important safety, reliability, or performance issues. Please take the time to read the correspondence carefully and take the necessary actions.

If you own more than one piece of HydraMaster equipment, multiple copies of the Product Support Bulletin (PSB) may be included along with a list of the serial numbers that this PSB applies to. After considering the content of the PSB, insert it into your equipment owner manual for future reference.

If you have any questions concerning this correspondence please contact your HydraMaster Customer Service Representative at the number listed below or visit our website at www.hydramaster.com.

Thank you for choosing HydraMaster as your source for professional cleaning products



Product Support Bulletin

To:	Titan 575 Owners		
Document #:	PSB-44276	Effective Date:	Nov 5, 2010
Title:	Titan 575 Vacuum Label		

As the manual states, the maximum vacuum level should be set to 12”Hg. Some of the early front dash labels did not have this information printed on them. We are supplying a label for your Titan 575 to add visibility to the maximum vacuum level allowed for operation of the machine. Please attach the supplied label below the vacuum gauge as shown.



Verify that the vacuum level is set at 12” Hg. Adjust the vacuum level as necessary with the vacuum relief valve located on the recovery tank.